

See back cover for
new features of v4.0

INSTALLATION MANUAL



PC1500

This device complies with Parts 15 and 68 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
FCC Registration Number: F53CAN-61031-AL-E REN = 0.0B Plug Type : RJ31X MADE IN CANADA

NOTES FOR UL INSTALLATIONS

This equipment is UL listed in accordance with standard UL1023 (Household Burglar - Alarm System Units), standard UL985 (Household Fire Warning Units) and UL1635 (Digital Alarm Communicator System Units).

This equipment has the capability of being programmed for operational features that are not allowed for UL recognized installations. To stay within the standard for household applications, the installer should use the following guidelines when configuring the system.

1. ALL components of the system should be UL listed for the intended application. Note elsewhere in this manual, recommendations for smoke detectors and battery to be used with this equipment.
2. If this system is configured for "Fire", the installer should refer to NFPA Standards #74 for details on locating smoke detectors. When the "Fire" feature is enabled, there must be at least one UL recognized indoor Fire Alarm Warning Signalling Appliance.
3. Maximum allowed entry time = 45 seconds
Maximum allowed exit time = 60 seconds
Minimum allowed bell cutoff time = 4 minutes
4. User bypass must be enabled so that a user code is required to bypass zones.
5. The installer should caution the user to NOT give system information to casual users, for example, Access Codes, bypass methods, etc., to babysitters or home service people. Only the "One-Time" use code should be given to the casual user.
6. The installer should advise the user and note in the user manual:
 - Service organization name and telephone number
 - The programmed exit time
 - The programmed entry time
7. Remote programming must be disabled.

TABLE OF CONTENTS

FEATURES	1
SPECIFICATIONS	1
INSTALLATION	2
Mounting the Panel	2
Mounting the Keypad	2
Auxiliary Power Connection	2
PGM Terminal Connections	2
Keypad Wiring	2
Bell/Siren Connection	2
Fire Zone Wiring	3
Burglary Zone Wiring	3
AC Power Wiring	3
Battery Connection	3
Telephone Line Wiring	3
GUIDELINES FOR LOCATING SMOKE DETECTORS	4
KEYPAD FUNCTIONS	5
Introduction	5
Master Code	5
2nd Master Code	5
Installer's Programming Code	5
Arming	5
Auto-bypass/Home-away Arming	5
Arming Without Entry Delay	5
Disarming	5
Zone Bypassing [*]+[1]	5
Trouble Conditions [*]+[2]	6
Alarm Memory [*]+[3]	6
Downloading Callup Command [*]+[4]	6
User Programming Command [*]+[5]+[Master Code]	6
EEPROM Reset	7
User Function Commands [*]+[6]+[Master Code]	7
Setting the Clock [*]+[6]+[Master Code]+[1]	7
Set Auto-Arm Time [*]+[6]+[Master Code]+[2]	7
Quick-Arm ON/OFF [*]+[6]+[Master Code]+[4]	7
Auto-Arm ON/OFF [*]+[6]+[Master Code]+[5]	7
Door Chime ON/OFF [*]+[6]+[Master Code]+[6]	7
Bell Test [*]+[6]+[Master Code]+[8]	8
Installer's Test ON/OFF [*]+[6]+[Master Code]+[0]	8
Utility Output Command [*]+[7] or [*]+[7]+[Access Code]	8
Installer's Programming Command [*]+[8]+[Installer's Code]	8
Arming without Entry Delay [*]+[9]+[Access Code]	8
Arming For The Night [*]+[1]	8
Quick-Exit [*]+[0] when Armed	8
Quick-Arm Command [*]+[0] when Disarmed	8
Keypad Zones	8
PROGRAMMING GUIDE	9
Introduction	9
Programming	9
Program Data Review	9
Binary Data Display	10
HEX Data Programming	10

PROGRAMMING SECTIONS	11
[00] Binary Programming	11
[01] 1st Phone Number	11
[02] 1st Account Code	11
[03] 2nd Phone Number	11
[04] 2nd Account Code	11
Reporting Codes [05] to [10]	11
[05] Zone Alarm Reporting Codes	11
[06] Zone Restoral Reporting Codes	11
[07] Closing (Arming) Reporting Codes / Partial Closing Reporting Code	12
[08] Opening (Disarming) Reporting Codes / After Alarm Reporting Code	12
[09] Priority Alarms and Restorals	12
[10] Maintenance Alarms and Restorals	12
[11] Zone Definitions	12
[12] 1st System Option Code	13
[13] 2nd System Option Code	14
[14] 3rd System Option Code	14
[15] Communication Variables	14
[16] Zone Bypass Mask	14
[17] System Times	14
[18] Auxiliary Delay Zone Entry / Exit Times	15
[19] System Clock Times	15
[20] New Installer's Code	15
[21] New Master Code	15
[22] 2nd Master Code	15
[23] Communication Formats	15
[24] Programmable Output Options (PGM Terminal)	16
[25] Communicator Call Direction	16
[26] Downloading Telephone Number	17
[27] Downloading Access Code	17
[28] Panel Identification Code	17
[29] For Future Use	17
[30] Reset to Factory Default	17
[31] 4th System Option Code	17
[32] 5th System Option Code	17
[33] For Future Use	17
[34] 6th System Option Code	17
[35] For Future Use	18
[36] Keypad Lockout Control	18
[90] Installer's Lockout Enable	18
[91] Installer's Lockout Disable	18
FOR THE RECORD	19
PROGRAMMING WORK SHEETS	20 - 28
HOOKUP DIAGRAM	29
LIMITED WARRANTY	30
FCC COMPLIANCE STATEMENT	30

FEATURES

Keypad Programmable

The PC1500 is complete with a default program so that it is operational with a minimum of programming. The control panel is completely programmable from the keypad.

EEPROM Memory

The panel uses EEPROM memory which will retain all program information even if AC and battery power is removed from the panel. The EEPROM memory can be reprogrammed thousands of times.

Static/Lightning Protection

The PC1500 has been carefully designed and tested to provide reliable protection against static and lightning induced transients. Our special "Zap-Trac" circuit board design catches high voltage transients right at the wiring terminals, and transient protection devices are placed in all critical areas to further reduce damaging voltages.

Supervision

- Low or disconnected battery
- Loss of AC power
- Fuse open
- Loss of time on system clock
- Microprocessor "Watchdog" circuit

Operation

- Download / Upload capability
- Programmable auto downloading
- Swinger shutdown
- Transmission delay
- Six access codes
- Master Code
- All zones programmable as fire zones
- Programmable test transmission
- Zone bypass from the keypad
- Six zones
- Bell / Siren zone
- Programmable output
- Three dedicated keys (Fire/Auxiliary/Panic)
- Backlit aesthetically pleasing keypad

SPECIFICATIONS

PC1500 Control Panel

- Six fully programmable zones
 - EOL resistor supervised option
 - all zones programmable as fire zones.
 - maximum zone loop resistance 100 ohms
- Bell / Siren outputs: 1 amp
 - steady for burglary
 - pulsed for fire
- Programmable output: 300 mA
 - 9 programmable options
- Auxiliary power output: 475 mA
- PC1500RK keypad: 3 maximum
- Battery: 12 VDC, 4 Ah minimum
- Transformer: 16 VAC, 40 VA
- Panel dimensions:
 - 10" H x 8" W x 3" D (254 mm x 208 mm x 76 mm)
 - Surface mount
- Panel colour: beige

PC1500RK Keypad

- Three keypad activated zones: Fire, Auxiliary, Panic
- Backlit keys
- 5 system lights: Ready, Armed, Memory, Bypass, Trouble
- 6 zone lights
- Keypad dimensions
 - 4.5 H x 4.5 W x 0.93" D (114 mm x 114 mm x 23.6 mm)
 - Surface mount
- Keypad colour: mist

INSTALLATION

Mounting the Panel


Select a dry location close to an unswitched AC source and close to the telephone line connection. Remove the printed circuit board, the mounting hardware and the keypad from the cardboard retainer inside the cabinet. Before attaching the cabinet to the wall, press the four white nylon printed circuit board mounting studs into the cabinet from the back. Once the cabinet is mounted to the wall, pull all the cables into the cabinet and prepare them for connection. Use a meter to test the wiring for opens, shorts and grounds. Press the circuit board onto the white nylon mounting studs. Complete all wiring to the control panel before applying AC power or connecting the battery.

Mounting the Keypad

Keypads should be located close to the designated "Entry-Exit" door(s) and mounted at a height convenient for all users.

NOTE: Complete all wiring to the control panel before applying AC power or connecting the battery.


Auxiliary Power Connection



The auxiliary power supply can be used to power keypads, motion detectors and other devices that require 12 VDC. See the Fire Zone Wiring section for the connection of 4-wire smoke detectors. The total load for the auxiliary power output must be calculated for all devices connected across the AUX +/- terminals and for devices connected between the AUX + and PGM terminals. The output

current cannot exceed 475 mA. Allow 35 mA for each PC1500RK keypad connected to the panel.

PGM Terminal Connections



The PGM terminal is a switched negative output which can be controlled by various programming options (See Programming Guide Section [24]). Devices controlled by the PGM output must be connected between the PGM terminal, which is (-) and the AUX (+) terminal.

Keypad Wiring


Up to three keypads may be connected in parallel. Do not connect multiple keypads on the same keypad wire run. For Standby Loading purposes, use a current draw of 35 mA per keypad. This represents the panel in the disarmed state with two zones open.

The wiring table gives the wire run length from the control panel to the keypad for various gauges of wire. Wire run lengths are based on the maximum current drawn by the keypad. (All lights ON).


If two wires of the same gauge are paralleled, the run length can be doubled. eg. If 8 #22 AWG wires are used, 2 red, 2 blk, 2 grn and 2 yel, the run length would go from 420' to 840' (127 to 254 m).

Wiring Chart PC1500RK

Wire Gauge (AWG)	Max. Run Length Keypad to Panel
24	260' (79m)
22	420' (127m)
20	660' (200m)
19	830' (252m)
18	1050' (318m)



Bell/Siren Connection



Bell Loop Wiring Chart


Current mA	AWG 14	AWG 16	AWG 18	AWG 19	AWG 22
	Distance to last bell or siren (ft./m.)				
100	2375/724	1500/457	940/287	750/229	370/113
200	1190/363	750/229	470/143	370/113	185/ 56
300	790/241	500/152	310/ 94	250/ 76	120/ 37
400	595/181	375/114	235/ 72	185/ 56	90/ 27
500	475/145	300/ 91	190/ 58	150/ 46	75/ 23
600	400/122	250/ 76	155/ 47	125/ 38	60/ 18
700	340/104	210/ 64	135/ 41	105/ 32	50/ 15
800	300/ 91	190/ 58	115/ 35	90/ 27	45/ 14
900	265/ 81	170/ 52	100/ 30	80/ 24	40/ 12
1000	240/ 73	150/ 46	90/ 27	75/ 23	35/ 11

Wire run distances are in feet/meters from the control panel to the last device on the loop. Calculations are based on 12 VDC at the panel with a maximum 10% voltage drop at the last device. Observe polarity when connecting siren drivers, sirens and polarized bells.

Fire Zone Wiring

Any one of the 6 zones may be programmed as a Fire Zone. See Programming Guide Section [11].

Smoke detectors should be the latching type and have N.O. alarm initiating contacts. Power wiring from the AUX + / PGM terminals should be supervised using an RM-1 relay after the last smoke detector. The RM-1 N.O. contacts (closed with power applied) should be wired in series with the alarm initiating end-of-line resistor so that should power to the detector(s) fail, a fire zone trouble will be initiated.



Fire Zone Power Wiring Chart

Current mA	Max. Wire Run to E.O.L. Relay				
	AWG 14	AWG 16	AWG 18	AWG 19	AWG 22
50	4750' 1447m	3000' 914m	1880' 573m	1500' 457m	750' 228m
100	2375' 723m	1500' 457m	940' 286m	750' 228m	370' 112m
200	1190' 362m	750' 228m	470' 143m	370' 112m	180' 56m
300	790' 240m	500' 152m	310' 94m	250' 76m	120' 36m
400	595' 181m	375' 114m	235' 71m	185' 56m	90' 27m

Wire run distances are in feet/meters from the Aux. +/- terminals to the End-Of-Line Power Supervisory Relay. Figures are based on 12 VDC at the Aux +/- terminals with a maximum 10% voltage drop at the RM-1 relay.


Alarm Initiating Loop Wiring Chart

Wire Gauge	AWG 14	AWG 16	AWG 18	AWG 19	AWG 22	AWG 24
Distance to EOL Resistor	19 800' 6035m	12 450' 3794m	7800' 2377m	6200' 1889m	3000' 914m	1900' 579m

Figures based on maximum loop resistance of 100 ohms.

Burglary Zone Wiring

Burglary zone definitions (Delay, Instant, 24-Hour, etc.) are programmed in Programming Section [11].



Zone Wiring Chart

Wire Gauge (AWG)	Max. Run Length to End-of-Line resistor
24	1900' (579m)
22	3000' (914m)
20	4900' (1493m)
19	6200' (1889m)
18	7800' (2377m)

Figures based on maximum loop resistance of 100 ohms.

AC Power Wiring

Complete all wiring to the control panel before connecting AC power or the battery. Only when all wiring is complete, connect a 16VAC 40VA minimum transformer to the AC terminals. Do not connect the transformer to a receptacle controlled by a switch. The transformer must be UL-listed and have a restraining means.

Battery Connection

If the battery is reverse connected, the 5 A fuse will blow. The battery charging voltage is factory set and normally needs no adjustment. If the battery charging voltage is out of adjustment, contact your service representative. If AC power is OFF and the battery voltage is approximately 9.5 V or lower, the battery will be disconnected and the panel will power down. To power up again, the AC will have to be re-established.

NOTE: The battery charging voltage must not be adjusted on UL-listed systems.

Telephone Line Wiring

NOTE: Ensure that plugs and jacks meet the dimension, tolerance and metallic plating requirements of 47 C.F.R. Part 68, Subpart F.

WARNING: FCC restricts using this equipment on certain types of telephone lines. Read FCC Compliance Statement at the end of this manual. Also, do not use this equipment on a telephone line equipped with a “call holding” feature, as the tone generated may interfere with the communicator operations.

Do not connect the alarm panel communicator to telephone lines intended for use with facsimile (FAX) machines. These lines may incorporate a voice filter which disconnects the line if other than FAX signals are detected, resulting in incomplete transmissions.

GUIDELINES FOR LOCATING SMOKE DETECTORS

Experience has shown that all hostile fires in family living units generate smoke to a greater or lesser extent. Experiments using typical fires in family living units indicate that detectable quantities of smoke precede detectable levels of heat in most cases. For these reasons, NFPA standard 74 requires smoke detectors to be installed outside of each sleeping area and on each additional story of the family unit.

The following information is for general guidance only and it is recommended that NFPA standard 74 be consulted and that the smoke detector manufacturer's literature be used for detailed installation instructions.

It is recommended that additional smoke detectors beyond those required be installed for increased protection. The added areas include: basement, bedrooms, dining rooms, furnace room, utility room and hallways not protected by the required detectors.




Figure 3: A smoke detector should be located on each story of the living unit.




Figure 1: A smoke detector should be located between the sleeping area and the rest of the family unit.





Figure 2: In the family living units with more than one sleeping area, a smoke detector should be located to protect each sleeping area.



NOTE: Measurements shown are to the closest edge of the detector.

Figure 4: Smoke Detector Mounting and "Dead" Air Space. The smoke from a fire generally rises to the ceiling, spreads out across the ceiling surface and begins to bank down from the ceiling. The corner where the ceiling and wall meet is an air space into which the smoke may have difficulty penetrating. In most fires, this "dead" air space measures about 4 in. (0.1m) along the ceiling from the corner and about 4 in. (0.1m) down the wall as shown in Figure 4. Detectors should not be placed in the "dead" air space.

KEYPAD FUNCTIONS

Introduction

The PC1500RK remote keypad provides complete information and control of the PC1500 control panel. The panel can be fully programmed from the keypad. The 6 zone lights provide alarm and status indication for the alarm circuits. Each zone can be programmed to be a burglary zone or a fire zone. The five function lights guide the user in operating the system and the built-in sounder lets the user hear correct key entries and other alert signals. The 12 digit keypad is used for code entry and other programming functions. The single button [F]ire, [A]uxiliary and [P]anic keys provide the user with simple operation for emergency signalling. All keypad entries are made by pressing one key at a time.

Master Code

A default Master Code "1234" is factory programmed into the PC1500. The Master Code is used to arm and disarm the panel, to reset the bells after an alarm, to program up to 11 additional codes using the [*][5] command, and to enter other user functions using the [*][6] command. The panel default program allows the user to change the Master Code. The panel can be programmed, by the installer, so the user cannot change the Master Code. See 2nd System Option Code light 2.

2nd Master Code

A second Master Code can be programmed into the PC1500. This code can be changed by the installer only, and is useful where there are multiple panels in a complex. The 2nd Master Code may be used as a "Master Key". The default 2nd Master Code is blank.

Installer's Programming Code

A default Installer's Programming Code "1500" is programmed into the PC1500. Using this code and the [*][8] command, the installer can gain access to the system to enter panel program information. This code can be changed by the installer.

Arming

Before arming the panel, close all protected doors and windows and stop movement in areas covered by motion detectors. If the "Trouble" light is on, check for the type of trouble ([*][2] command) and correct the fault condition. If the "Bypass" light is on, insure that the zones bypassed are bypassed intentionally, ([*][1] command). If the "Ready" light is not on, one or more zones are open. The system can only be armed when the "Ready" light is ON. To arm, enter a 4 digit access code. As each digit is entered, the keypad sounder will beep. When the correct access code has been entered the "Armed" light will come ON and the keypad will beep 6 times. If the access code has been entered incorrectly, the keypad will sound one long tone. Press the [#] key and enter the access code again.

When the correct access code has been entered and the "Armed" light is ON, exit through the designated entry/exit door before the Exit Delay time expires. At the end of the allowed exit time, all lights on the keypad will go out except the "Armed" light. The "Bypass" light will be ON if a zone is bypassed and if Show Bypassed Status While Armed is programmed in Section [31], zone light 4 ON.

See Installer's programming Section [*][8] command for instructions on changing the Exit Delay time.

Auto-bypass/Home-away Arming

If a correct access code is entered, and you **do not** exit the premises, the system will, at the end of the Exit Delay time, arm with interior zones automatically bypassed if those interior zones have been programmed as "Home-away" zones. The "Bypass" light will come ON. (See programming Section [11], Zone Definitions for programming zones as "Home-away").

This is a convenience feature for the user who wishes to remain at home with the system armed. The user does not have to manually bypass the interior zones.

To reactivate the interior zones that have been automatically bypassed, press [*][1]. The "Bypass" light will go out. If the bypassed zones were programmed as Home-away with delay, the "Bypass" light will go out after the delay. This command is a quick method of fully arming the system before going to bed and is useful for the user who has a keypad outside the areas protected by the interior zones.

Arming Without Entry Delay

To eliminate the Entry Delay, arm the system using [*][9], [any valid access code]. An exit may be made as in normal arming. The system will arm as described above in Auto-bypass / Home-away arming whether an exit is made or not. The "Armed" light will flash to indicate that the system is armed without the Entry Delay.

Disarming

Enter the premises through the designated entry-exit door. The keypad sounder will be on as a reminder to disarm the system. Go to the keypad and enter a valid access code. If an error is made entering the code, press the [#] key and enter the code again. The "Armed" light will go out and the sounder will stop. The correct access code must be entered before the entry time expires or the panel will go into alarm. To change the entry time see Installer's Programming Section [17].

If an alarm occurred while the panel was armed, upon disarming the "Memory" light and the zone light(s) of the zone(s) that caused the alarm will flash for two minutes. Pressing the [#] key will stop the flashing, extinguish the zone light(s) and return the panel to the ready mode. The "Memory" light will stay on steady to indicate that an alarm did occur during the last armed period. To view the zone(s) that caused the alarm, see Alarm Memory Display [*][3].

Zone Bypassing

[*]+[1]

A bypassed zone will not cause an alarm. Use zone bypassing when access is needed to part of a protected area or if damage to contacts or wiring cannot be repaired immediately. The panel can be armed with one or more zones bypassed even if the zone(s) are open. The "Ready" light will be ON and the "Bypass" light will be ON if a zone is bypassed. A fire zone **cannot** be bypassed.

If the "Bypass" light is ON when arming, use the [*][1] command to display the bypassed zones and ensure that any zone displayed as being bypassed is intentionally bypassed.

Zone bypasses are automatically cancelled when the panel is disarmed.

To Bypass Zones:

Enter [*][1] - the "Bypass" light will start flashing.

Enter [zone number to be bypassed]; the zone light will come ON to indicate that the zone is bypassed. To remove a bypass, enter the zone number and the zone light will go OFF. Continue entering the zone numbers for the zones you want bypassed. Press [#] to return to Ready.

To Recall Bypassed Zones:

Enter [*][1][9]

This command will recall the last zone or group of zones that were bypassed. If the same group of zones are bypassed regularly, the bypass recall feature can be used instead of bypassing the zones individually.

Bypass Disable:

The PC1500 can be programmed by the installer to prevent certain zones from being bypassed by the user. Lights for these zones will not come ON in response to the bypass command. See the Zone Bypass Mask instruction in the installer programming Section [16].

Trouble Conditions

[*][2]

The PC1500 continuously monitors a number of trouble conditions. If one of these conditions occurs, the keypad "Trouble" light will come ON and the buzzer will sound two short beeps every 10 seconds. To silence the buzzer, press the [#] key. The buzzer will stop but the "Trouble" light will remain ON until the trouble condition is cleared. See the Programming Guide Section [10], Maintenance Alarms & Restorals for a list of trouble conditions that can be transmitted to the monitoring station.

To view the trouble condition, press [*][2].

1. Low Battery. If the battery voltage is low, the battery is disconnected or the battery fuse is blown, a trouble will be displayed and can be reported.

2. AC Failure. On loss of AC power, the "Trouble" light will come ON immediately, but the keypad buzzer will not sound. The keypad buzzer will sound if AC power remains off and the battery reaches a low voltage. The delay before transmitting AC Fail can be programmed from 1 to 99 minutes. See Programming Section [17].

3. Fuse Failure - Bell / Siren or AUX Output. A trouble is displayed if the Bell / Siren fuse is open. If the AUX output fuse fails, it will not be displayed but will be transmitted if programmed to do so.

4. Unsuccessful Communication Attempt If the digital communicator is unsuccessful at communicating with the monitoring station after 8 attempts at each phone number that is tried, a trouble is generated. See Section [25], Communication Variables. If a later attempt at communication is successful, the trouble is cleared. The trouble can also be cleared by pressing the [#] key to exit from the trouble view mode.

5. Fire Alarm Circuit Trouble An open circuit on the zone programmed as a Fire Zone will initiate a trouble. See Zone Definitions Section [11] for Fire Zone assignment.

6. Loss of Time on System Clock... When the PC1500 is powered up or reset, the internal time of day clock needs to be reset to the correct time. The trouble is cleared after entering the trouble view mode then pressing [#] to exit. The trouble will also be cleared on any attempt to set the time of day. See [*][6] User Function Command for setting the clock. Press [#] to return to Ready. NOTE: A trouble will not be generated if both the test transmission and Auto-Arm times are not programmed with valid times.

NOTE: If [9] is pressed while in the trouble display mode, the most recent trouble will be displayed on the zone lights. This trouble memory is most useful as a diagnostic tool when installing and servicing the PC1500.

Alarm Memory

[*][3]

Alarms caused during the previous armed period are stored in memory. To view these alarms, press [*] then [3]. The "Memory" light will flash and the alarm(s) will be displayed on the flashing zone lights.

In addition to the last alarm memory, there are two history levels. After entering the memory mode, pressing any key [0] to [9] will display the two other levels of alarm history. Each time a key is pressed, the keypad will beep 1, 2 or 3 times to indicate which level of history is being viewed.

When the panel is armed, and if there is an alarm in the 1st level, the 1st level is cleared and the contents moved to the 2nd level. The 2nd level contents are moved to the 3rd level and the 3rd level contents are discarded. The "Memory" light will be ON only if there was an alarm during the previous armed period. Press [#] to return to Ready.

Downloading Callup Command

[*][4]

The [*][4] command is used to initiate a call to the downloading computer so that the panel can be accessed by the computer. This command must be enabled in Section [14], 3rd system option code, zone light 2. Sections [26], [27] and [28] must be programmed with the downloading computer's telephone number, the downloading access code and the panel identification code. NOTE: The [*][4] command can be programmed to require a access code (e.g. [*][4][4-digit access code]) if Section [14] light 4 is turned ON.

User Programming Command

[*][5]+[Master Code]

The [*][5] programming command allows the user to program access codes 2 through 6. The 1st access code is the Master Code, which the installer may choose not to allow the user to program (Section [13] light 2). The factory default for the Master Code is "1234". The 6th code may be changed from a regular code into a "one-time" use or "Maid's Code". See Section [13] light 5.

NOTE: The One-time Use code is only cleared when it is used to arm. If the Quick-Arm command [*][0] is used to arm, the "one-time" code will **not** be erased.

Programming Access Codes

Enter [*][5][Master Code] to enter the access code programming mode. The “Memory”, “Bypass” and “Trouble” lights will begin to flash. The zone lights are used to indicate the program status of the 6 access codes.

Zone Light	Access Code Status
OFF	Code not programmed
ON steady	Code programmed
Flashing	Code being programmed

Upon entering this programming mode, the 1st zone light will be ON to indicate that the Master Code is programmed with the Factory Default Code. The Master Code may be changed here or in Section [21] if the installer chooses to disable user-changing of the Master Code.

Changing or Adding a Code

To change access codes 1 to 6, press the corresponding key (1 to 6). The corresponding zone light will begin to flash. Enter the new four digit number. Do not use the [*] key or [#] key when entering the four digit number. After the four digits are entered, the keypad will beep 3 times and the zone light will come on steady. If you are changing an existing code, the new code will simply replace the old one. If you wish to program another code, press the number key for the code to be programmed and enter the new 4-digit code. Press the [#] key to exit this section.

Erasing a Code

To erase a code, enter [*][5][Master Code]. Press the key of the code you wish to erase. The zone light for that code number will flash. Enter [****].

NOTE: The Master Code cannot be erased. If the Master Code is forgotten and the panel is left disarmed, program a new Master Code using the [*][8][Installer's Code][21] command or use the 2nd Master Code to reprogram the Master Code.

EEPROM Reset

If the Master Code is forgotten and the panel is armed, see Programming Section [30] for software and hardware methods of resetting the panel to the factory default condition. Reset is not necessary if the 2nd Master Code is programmed.

User Function Commands

[*][6]+[Master Code]

This function is used to set the System Clock time and to set the Auto-Arm time as well as toggle a number of system functions. As soon as the command is entered, the “Memory”, “Bypass” and “Trouble” lights begin to flash.

Enter [*][6][Master Code][Number from list below].

- [1] System 24 Hr. Clock (Enter HH:MM)
- [2] Auto-Arming Time (Enter HH:MM)
- [3] [Reserved for future use]
- [4] Quick-Arm Enable/Disable
- [5] Auto-Arm Enable/Disable
- [6] Door Chime Enable/Disable
- [8] Bell Test Function
- [9] [Reserved for future use]
- [0] Installer's Test (turn off after use)
(This function will turn off automatically on arming.)

Items [4], [5], [6] and [0] turn ON and OFF various features. When the item key is pressed and the feature is being turned ON, the keypad sounder will beep 3 times. If the feature is being turned OFF the sounder will give one long beep. Pressing item [8] gives a 2-second Bell / Siren and Keypad Light and Buzzer test.

Setting the Clock

[*][6]+[Master Code]+[1]

The System Clock is a 24-hour clock and times must be entered as 2-digit numbers.

e.g. HH - 01, 02, 10, 11, 23, 00
MM - 01, 02, 35, 36, 58, 59
8:05 AM would be entered as 0805
1:30 PM would be entered as 1330

Setting the system 24 Hr. clock tells the system the time of day. If the system is without power, (AC and battery), it cannot continue to keep time. When the panel is powered up, the system clock must be reset. If the time needs to be reset, then a trouble #6 will be indicated on the keypad. (See [*][2] System Trouble Display). Trouble #6 will not be generated if the Auto-Arm time is not programmed with a valid time (9999 in these positions disables these features; refer to Section [19]).

Set Auto-Arm Time

[*][6]+[Master Code]+[2]

The PC1500 can be programmed to arm at the same time each day. At the selected Auto-Arm time, the bell will sound one short burst every 10 seconds for a one minute period if Section [32] light 2 is off. The keypad will also sound for one minute. If any key is pressed during the 1 minute warning period, Auto-Arming will be aborted. Auto-Arming will be attempted at the same time the next day. To set the Auto-Arm time, enter [*][6][Master Code][2] then enter the hours and minutes as described at the beginning of this section. This feature must also be enabled (see item [5] below).

Quick-Arm

ON/OFF [*][6]+[Master Code]+[4]

Pressing [4] while in the User Function Command mode will Enable (3 beeps) or Disable (one long beep) the Quick-Arm feature. With this feature enabled, the panel can be armed by simply entering [*][0].

Auto-Arm

ON/OFF [*][6]+[Master Code]+[5]

Pressing [5] while in the User Function Command mode will enable (3 beeps) or disable (one long beep) the Auto-Arm feature. With this feature enabled, the panel will automatically arm at the same time each day. The time is set in Section [19] or [*][6][Master Code][2].

Door Chime

ON/OFF [*][6]+[Master Code]+[6]

Pressing [6] while in the User Function Command mode will enable (3 beeps) or disable (one long beep) the Chime feature. With this feature enabled, the keypad will beep 5 times when any zone defined as a delay or instant circuit opens or closes. The Door Chime feature does not operate on other zone definitions. Zone Bypass may be used to eliminate beeping on zones where it is not wanted. The Door Chime feature functions only while the panel is in the Disarmed mode.

Bell Test

[*]+[6]+[Master Code]+[8]

Pressing [8] while in the User Function Command mode will sound the bell/siren, the keypad sounder and turn on all the keypad lights for 2 seconds.

Installer's Test

ON/OFF [*]+[6]+[Master Code]+[0]

Pressing the [0] key while in the User Function Command mode will enable/disable the Installer's Test function. This feature facilitates final testing of the system and when enabled, the bell/siren will operate for 2 seconds each time a zone is put into alarm. Each zone should be tripped individually to avoid confusion about which zone originates the alarm. To exit the Installer's Test mode, arm then disarm the panel.

NOTE: The communicator will transmit all alarms and restorals. Disable the communicator if this is not desired (Section [12], light 1).

Utility Output Command

[*]+[7] or [*]+[7]+[Access Code]

The Programmable Output (PGM terminal) can be programmed for activation by a keypad command. This output can be used to operate other devices such as door openers, special lighting, door strikes or to reset smoke detectors. (See Programming Section [24], item 2, 3 or 4). Depending on the option chosen, the [*][7] command may or may not require a subsequent access code.

When the correct command is entered, the keypad sounder and the PGM output will operate for 5 seconds.

Installer's Programming Command

[*]+[8]+[Installer's Code]

The PC1500 is completely programmed from the keypad by using commands in the [*][8] section. These commands are described in detail in the programming section of this manual. The default Installer's Code is [1500].

Arming without Entry Delay

[*]+[9]+[Access Code]

Entering [*][9] before the arming code will arm the panel without the Entry Delay on delay zones. Also "Home-away" zones are automatically bypassed. When armed using the [*][9] command, the "Armed" light will flash to remind the user that the system is armed without the Entry Delay. This command allows the user to remain at home and have an instant alarm on the entry doors.

Arming For The Night

[*]+[1]

To reactivate "Home-Away" zones that have been bypassed by arming with the [*][9] command, enter [*][1]. When this command is entered, the "Armed" light will continue to flash to remind the user that the Entry Delay is not applied to the Delay Zones. Also, the "Bypass" light will be shut OFF to indicate that the Home-Away zones are no longer bypassed. Note that the [*][1] command will not remove bypasses from zones that have been manually bypassed.

Quick-Exit

[*]+[0] when Armed

Entering [*][0] when the system is armed will allow the user to exit the premises through any delay zone without altering the status of the system if the Quick-Exit feature is enabled. The Quick-Exit feature can be enabled by turning on option 4 in programming Section [32]. For 2 minutes after [*][0] is entered into an armed system, one and only one delay zone may be tripped. Any additional activity on any other active zone will cause that zone to begin its alarm sequence.

Quick-Arm Command

[*]+[0] when Disarmed

Entering [*][0] is accepted as a valid arming code if the Quick-Arm feature is enabled. This command is often used when individuals are required to arm the system but not disarm the system. This could be used with home visitors in the case of a residential alarm system or for junior employees and maintenance staff in the case of commercial systems. See [*][6] User Functions Command section, for enabling and disabling the Quick-Arm feature.

Keypad Zones

[F] - [A] - [P]

There are three zones which can be activated with single key entries on the keypad. For the [F], [A] and [P] keys to be functional for transmission, they must be enabled by the installer by entering the Alarm and Restoral Codes in Programming Section [09].

[F]ire Key Pressing the [F] key and holding it for 1 second will initiate a local pulsing alarm and, if programmed, will transmit the alarm to the monitoring station. The keypad will sound a series of short beeps once the panel has accepted the alarm.

[A]uxiliary Key Pressing the [A] key and holding it for 1 second will, if programmed, transmit an Auxiliary alarm to the monitoring station. There is no local alarm and no keypad lights will come ON when this key function is activated. The keypad will sound a series of short beeps upon successful completion of the transmission to the monitoring station.

[P]anic Key Pressing the [P] key and holding it for 1 second will, if programmed, send a transmission to the monitoring station. The alarm signal can be programmed to be *audible* or *silent*. See Programming Section [12], 1st System Option Code, Light 6. If programmed as *audible*, the local bell / siren will sound steadily.

Keypad audible annunciation for the [P] key is programmable, Section [14], Light 5, for feedback (3 beeps) or silent (no buzzer feedback). If programmed for *audible*, the buzzer will sound once the key input is accepted.

PROGRAMMING GUIDE

Introduction

The PC1500 is fully programmable from the keypad and uses an EEPROM memory which can be reprogrammed thousands of times. The EEPROM memory will not lose the program data even on total loss of power. The essential information which defines the operation of the control panel is stored in a section of the EEPROM memory which is accessible using the Installer's Programming code or via downloading. If the Installer's code is forgotten, the EEPROM may be reset to the factory default code. See Section [30], Reset to Factory Default.

Programming

With the panel in the disarmed mode, enter [*][8][1500]. The panel can only be programmed while it is in the disarmed mode. The default installer's code is 1500; the installer's code can be changed. See Section [20], New Installer's Code.

Once the installer's command is entered, the "Armed" light will come ON steadily and the "Memory", "Bypass" and "Trouble" lights will flash. This indicates that the panel is ready for programming. NOTE: If no key entry is made for 2 minutes, the panel will return to the Ready mode and the complete installer's command will have to be entered before programming can be resumed.

With the "Armed" light ON steadily, enter 2 digits for the section you wish to program. The sections for the PC1500 panel range from [01] to [36], and each section can be programmed independently. Section [00] is reserved for binary programming which is normally done on instruction from factory technical personnel.

Once the 2 digits for the section you wish to program are entered, the "Armed" light will go OFF, the "Ready" light will go ON steadily, and the keypad sounder will beep 3 times. The keypad is now ready to accept data for the selected section.

Most sections contain groups of 2-digit entries and the keypad buzzer will beep twice after each 2-digit group is entered.

When the section is first entered, the first 4 zone lights will indicate, in a binary format, the value of the first digit in that section (refer to "Binary Data Display" on the next page). If you wish to change that digit, simply enter the new digit from the keypad. If you wish to keep that digit unchanged, you can enter the same number or skip the digit by pressing the [F] key. Once the first digit has been entered or skipped, the 4 zone lights will display the value of the second digit. After each digit is entered or skipped, the zone lights show the value of the next digit in the binary format.

When the required data for the section being programmed is completely entered, the keypad sounder will beep several times and the "Armed" light will come ON to indicate that the expected data has been entered.

At this point, you will still be in the program mode and need only enter the section number for the next section you wish to program.

It is not necessary to program all 2-digit pairs in any given section. A section can be entered and selectively programmed by going only to the digit(s) you wish to change and then pressing [#] to return to the programming mode where you can then enter another section number for programming. For 2-digit pairs, both digits must be programmed before pressing the [#] key. Only the data entered before pressing the [#] key will be changed in the EEPROM.

Program Data Review

- Enter the section you wish to program by entering the 2-digit section number.
- The first 4 zone LEDs will represent the value, in binary format, of the first digit in that section.
- Each press of the [F] key will advance the display to the next digit.
- At the end of the section, the keypad will beep several times and then return to the program mode so that another section can be selected for review or programming.

NOTE: Only Sections [01] through [11], [15], and [17] through [28] can be reviewed using the method described above.

Sections [12], [13], [14], [16], [31], [32], [34]

These sections use the zone lights to indicate which functions are active and which number key to press to turn them ON and OFF. When one of these sections is entered, zone lights 1 to 6 will display which functions are currently ON. Pressing the key number corresponding to the zone light number will alternately turn the function ON and OFF, and the zone light will correspond to this. All functions can be turned OFF at once by pressing [0]. When the correct selections have been made, press [#] to save the selections in memory and return to the program mode where another section can be selected.

Binary Data Display

Zone lights 1 through 4 are used to display the value, in binary format, of the data as shown in the table below.

Value	Hex Data Entry*															
	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
Zone 1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>
Zone 2	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Zone 3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Zone 4	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

☒ Light On

☐ Light Off

* See Hex Data Entry instructions

HEX Data Programming

Certain programming entries may require the entry of data in HEX (hexadecimal, or base 16) format. HEX numbering uses the digits 0 through 9 and the letters A through F.

The letters A through F are represented by the number keys 1 through 6. To enter data in HEX format, first press the [*] key. The “Ready” light will flash. Enter the HEX value, then press the [*] key again to return to the normal entry mode. The “Ready” light will stop flashing.

To enter HEX numbers:

- A ➤ Enter [*][1][*]
- B ➤ Enter [*][2][*]
- C ➤ Enter [*][3][*]
- D ➤ Enter [*][4][*]
- E ➤ Enter [*][5][*]
- F ➤ Enter [*][6][*]

Enter [*] **before** and **after** each digit. The last digit in each section does not require the final asterisk ([*]) to be entered.

PROGRAMMING SECTIONS

[00] Binary Programming

This section is normally used upon instruction from factory technical personnel for specialized programming not covered by the standard programming instructions.

[01] 1st Phone Number

This is the first telephone number the Communicator will dial. See Section [25], Communicator Call Direction.

After entering Section [01] for programming, enter the telephone number the same way you would dial it on a touch-tone phone. Press [#] after the last digit to complete the telephone number programming.

A second dial tone search, as required in a PBX system, can be added by programming a HEX 'D' between the digits in the phone number where it is required. To enter a HEX 'D', press [*] then [4] then [*].

Instead of a dial tone search, a pause of 4 seconds can be inserted between digits in a telephone number.

Enter [*, 2, *] to dial a '*' (HEX 'B')

Enter [*, 3, *] for a 4-second pause (HEX 'C')

The total number of digits, including dial tone searches and pauses, must not exceed 16. Remember, press [#] to complete entry of the telephone number.

When complete, enter two digits to program another section.

[02] 1st Account Code

The 1st Account Code is always transmitted to the 1st telephone number to identify the customer. Enter a 4-digit number. If the HEX digits 'A' to 'F' are required, remember to enter [*] before and after the digit entry.

Where a zero is required in the account code, enter HEX 'A' (*, 1, *) to transmit 10 pulses which will be interpreted as a zero by the monitoring station receiver.

If a 3-digit code is required, as in 3/1 formats, enter [0] as the LAST digit. The [0] represents a null digit where no pulses are transmitted.

[03] 2nd Phone Number

This is the second telephone number to which the communicator will dial. See [01] for programming instructions.

[04] 2nd Account Code

The second account code is always transmitted to the 2nd telephone number. See [02] for programming instructions.

Reporting Codes [05] to [10]

These sections are used to program the communicator reporting codes. A reporting code is transmitted along with the account code with each transmission. If the reporting codes are not programmed, no transmission will be sent when an event takes place (i.e. alarm, restoral, opening / closing, trouble, etc.). To prevent a transmission from being sent for any event in the following sections, leave it unprogrammed or enter [00] as the reporting code.

Section [05] and [06] each have 6 reporting codes. Sections [07], [08] and [10] each have 7 reporting codes, while Section [09] has 8 reporting codes. Once a section is entered, the system expects a series of 2-digit numbers to be

entered. The keypad beeps twice and the "Armed" light flashes after each 2-digit entry. After the last 2-digit number is entered, programming of the current section is complete. The keypad gives a series of beeps, the "Ready" light goes OFF and the "Armed" light comes ON. The keypad is then ready to accept the next 2-digit section number for programming.

When changing reporting codes in a section, you can scroll to the code you wish to change by pressing the [F] key. Only codes actually changed will be altered in the EEPROM. Press [#] to exit from the programming sequence.

[05] Zone Alarm Reporting Codes

Once Section [05] is entered, the panel expects 6 2-digit numbers for the Alarm Reporting Codes for zones 1 to 6. These codes are used by the communicator when there has been an alarm on zones 1 to 6.

Listed below are several programming examples and the resulting transmission using different formats for the reporting codes. Obtaining different formats requires entering data in the Account Code Section [02] or [04], the Reporting Code Sections [05] to [10], and the Communicator Format Section [23].

3/1 FORMAT - Non-extended reporting

Requires:

- 3-digit account code in sections [02] or [04].
i.e. Enter 1230 for account code 123
- Format Code [0], [1], [2], [3], [4] depending on receiver type in Section [23].
- Single line digit Alarm Reporting Code Section [05]
i.e. Enter [30] for single digit code 3 (0 = no pulses)

TRANSMISSION SENT: 123 3

4/2 FORMAT - Non-extended reporting

Requires:

- 4-digit account code in sections [02] or [04].
i.e. Enter 1234 for account code 1234
- Format Code [0], [1], [2], [3], [4] depending on receiver type in Section [23].
- 2-digit Alarm Reporting Code in Section [05]
i.e. Enter [31] for 2-digit code 31

TRANSMISSION SENT: 1234 31

3/1 FORMAT - Extended reporting

Requires:

- 3-digit Account Code in Section [02] or [04]
i.e. Enter 1230 for code 123
- Format Code [8], [9], [A], [B], [C] depending on receiver type in Section [23]
- 2-digit Alarm Reporting Code in Section [05]
i.e. Enter [31] for 2-digit code 31

TRANSMISSION SENT: 1st ROUND 123 3
2nd ROUND 333 1

If a transmission is not wanted for a particular reporting code, then enter '00' or 'FF' to disable that reporting code.

[06] Zone Restoral Reporting Codes

These reporting codes are used by the communicator to transmit zone restorals for zones 1 through 6. Use instructions in Section [05] above as a guide for programming.

[07] Closing (Arming) Reporting Codes

Partial Closing Reporting Code

Reporting codes 1 to 6 are used to identify closings for access codes 1 to 6. If partial closing is identified in Section [14], then alarm codes for manually bypassed zones will be transmitted when the system is closed with one or more zones bypassed.

When transmitting in 4/2, 3/1 or any other of the extended formats, see Section [05] above. The 6 closing codes are programmed as follows:

[C1], [C2], [C3], [C4], [C5], [C6]

Where the first digit HEX 'C' represents a closing signal and the second digit represents the user access code which was used to arm the system (HEX 'C' could be any other number depending on what is used at the monitoring station).

The closing code transmission takes place after the Exit Delay time. Therefore, if the system is armed and disarmed before the expiry of the exit time, no closing transmission will take place.

The partial closing code, if used, is transmitted in tandem with the regular closing code to identify the closing as a partial closing.

When the system has been armed using the Quick-Arm command [*][0] or using the Auto-Arm feature, access code #1 will be transmitted.

[08] Opening (Disarming) Reporting Codes

After Alarm Reporting Code

The first 6 reporting codes correspond to the 6 user access codes. When the system is disarmed using one of the access codes, the corresponding reporting code in this section is transmitted. See Section [07] above for examples of reporting code programming.

If the After Alarm Code is programmed, that code will be transmitted to the monitoring station on opening if an alarm occurred during previous armed period. This feature is useful for installations where openings and closings are not reported normally, but it is desired to have a report to the monitoring station on opening if an alarm did occur during the previous armed period. This feature allows the monitoring station to know when the user is on the premises and available to receive a report about alarms while the system was closed.

[09] Priority Alarms and Restorals

These reporting codes are used by the communicator to transmit the following list of troubles, alarms and restorals. See Section [05] as a guide for programming.

- Fire Zone Trouble.
- Keypad [P]anic Alarm.
- Keypad [F]ire Alarm.
- Keypad [A]uxiliary Alarm.
- Fire Zone trouble Restore.
- Keypad [P]anic Restore.
- Keypad [F]ire Restore.
- Keypad [A]uxiliary Restore.

Transmission for operation of the [F], [A] and [P] keys will only take place if the appropriate sections in [09] are programmed with a reporting code.

[10] Maintenance Alarms and Restorals

These reporting codes are used by the communicator to transmit the following list of alarms and restorals. See Section [05] as a guide to programming.

- Low Battery Alarm.
- AC Failure Alarm.
- Fuse Failure Alarm.
- Low Battery Rrestore.
- AC Failure Restore.
- Fuse Failure Restore.
- Automatic Test Code

The Test Code is not transmitted if periodic downloading is selected, Section [14], light 3. For Automatic Test Code Reporting, the time between reports (in days) must be entered in Section [17] and the time of day for the report must be entered in Section [19].

NOTE: For UL installations, either AC failure or battery trouble reporting must be enabled.

[11] Zone Definitions

As in the reporting codes sections, once this section is entered, 6 2-digit numbers are required. Each 2-digit number entered defines how a zone will operate.

Zone Definitions Digit #1

The first digit determines whether the zone will cause a silent alarm or an audible alarm and whether the zone response will be fast or slow. Zone response time can be programmed in Section [17] and can be set from 10 ms to 990 ms. The factory default zone response time is 500 ms. If set at fast, the zone response time is 10 ms, and if set at slow, the zone response time is 500 ms or whatever time is set in Section [17].

- [0] = slow & audible
- [1] = slow & silent
- [2] = fast & audible
- [3] = fast & silent

Zone Definitions Digit #2

Digit #2 determines the zone type, [0] through [8], as described below.

[0] Standard Delay Zone has an Entry and Exit Delay and is normally used for entry/exit doors. The Exit Delay starts as soon as the panel is armed. The zone may be opened and closed during the delay time without causing an alarm. After the Exit Delay time has expired, opening the zone will start the Entry Delay timer. During the Entry Delay time, the keypad buzzer will sound steadily to advise the user that the system should be disarmed. If the panel is disarmed before the entry time expires, no alarm will be generated.

The default times for this type of zone are a 30 second Entry Delay and a 120 second Exit Delay. The Entry and Exit Delays may be independently programmed in Section [17] for periods from 1 second to 255 seconds. All zones programmed as type [0] will have the Entry and Exit Delays as programmed in Section [17] or the default times if Section [17] is not programmed.

[1] Instant Zone is normally used for door and window contacts and has the standard Exit Delay but is instant when opened after the Exit Delay expires. The Exit Delay will be the default time of 120 seconds or the time as established in programming Section [17].

[2] Interior Zone is normally used with interior motion detectors and has the standard Exit Delay time. The zone also has the standard Entry Delay time provided that a delay zone has been tripped first. If the premises are entered without coming through a "delay" entrance, and a type [2] zone is tripped, an immediate alarm will be generated.

[3] Interior Home-away Zone operates the same as the type [2] zone with the following exception. If the system is armed and the delay zone is NOT tripped during the Exit Delay time, the type [3] zone will be bypassed. Instead of the interior portion of an interior Home-away zone, a Home-away zone can have a delay equal to the standard Entry and Exit Delay when Section [32], light 3 is ON. This will affect all Home-away zones when they are not bypassed by [*][1][*][9] arming, or by arming and not leaving the premises. If Home-away zones are automatically bypassed or [*][9] arming bypassed and the user then enters [*][1], the Home-aways will then have a delay.

[4] 24 Hour Bell is active at all times and will create an alarm if the panel is armed or disarmed. This zone will always activate the bell/siren output.

[5] 24 Hour Bell/Buzzer operates as the type [4] except the bell/siren output is activated only when the panel is armed and only the keypad buzzer is activated while the panel is disarmed.

[6] 24 Hour Buzzer operates as the type [4] except only the buzzer will be activated in the armed or disarmed mode.

[7] Auxiliary Delay Zone operates the same as the type [0] zone except the Entry/Exit Delays can be independently set in Section [18]. This zone type is useful when a zone with an Entry and/or Exit Delay is required that is different from the standard times as established for type [0] zones in Section [17]. If Section [32], light 5 is ON it will enable the system to be armed even if the auxiliary delay zone is open ("Ready" light ON). Also, the system can be armed with the auxiliary delay zone closed and then it can be opened before the Auxiliary Exit Delay has expired. In both cases the auxiliary delay zone will not become active until both the Auxiliary Exit Delay has expired and the zone is closed.

[8] Fire Zone Although a common fire signal is reported, any number of the 6 zones may be programmed as a fire zone. A fire zone is a supervised (N.O. alarm initiating contacts), end-of-line resistor circuit designed to accept latching 4-wire smoke detectors. See the fire circuit installation drawing.

On alarm, fire zone shorted, the bell / siren will pulse to indicate that a fire zone has been activated. Transmission by the digital communicator is delayed 30 seconds. If the alarm is acknowledged before the 30 second delay has expired, pressing the [#] key will silence the alarm and abort the transmission. If the alarm is NOT acknowledged within the 30 second period, transmission will proceed and cannot be aborted. If the alarm has been silenced and all smoke detectors are not restored to normal, the alarm will re-sound after 90 seconds; 30 seconds after that, the communicator will transmit. If the alarm re-sounds, it may again be silenced by pressing the [#] key and the communicator transmission will be aborted if the alarm is silence within the 30 second transmission delay period.

To restore the smoke detectors to normal, clear all

products of combustion from the detectors and perform a reset by pressing the [*] then [7] keys. See Section [24] for programming the PGM terminal for smoke detector reset. Pressing [*][7] will remove power from the smoke detectors for 5 seconds; if the detectors are clear of smoke, they will return to normal. If the detectors still have smoke in them, the alarm will re-sound and the sequence described above will repeat.

For an open on any zone programmed for fire, the "Trouble" light will come ON and the keypad sounder will beep every 10 seconds. The keypad trouble buzzer will sound and the "Trouble" light will come ON regardless of whether the panel is armed or disarmed. The communicator will transmit the trouble condition if programmed in Section [09]. The audible trouble indication may be silenced by pressing the [#] key. The "Trouble" light will only go OFF when all the fire zone troubles are cleared. To determine the type of trouble, press [*][2].

Section [11], Digit #2 Summary:

- [0] = Standard Delay Zone
- [1] = Instant Zone
- [2] = Interior Zone
- [3] = Interior Home/Away Zone
- [4] = 24 hour Bell Zone
- [5] = 24 hour Bell/Buzzer Zone
- [6] = 24 hour Buzzer Zone
- [7] = Auxiliary Delay Zone
- [8] = Fire Zone

[12] 1st System Option Code

The 1st System Option Code is set using the zone lights as shown in the table below. Once Section [12] is entered, the 6 zone lights will indicate the status of each option. Press a number key corresponding to the zone light number to turn the option ON and OFF. Pressing [0] will turn all the zone lights OFF and the options will be set as shown against "Light Off".

ZONE LIGHT

- [1] ON = Communicator disabled
 - OFF = Communicator Enabled
- [2] ON = Transmission per 24 hour period
 - OFF = Transmission per armed period
- [3] • ON = Alarm display while armed
 - OFF = No alarm display while armed
- [4] • ON = DTMF dialling*
 - OFF = Pulse dialling
- [5] ON = N.C. zones (except fire zones)
 - OFF = End-of-line resistor zones
- [6] • ON = Keypad [P]anic audible
 - OFF = Keypad [P]anic silent

• Factory default settings

* DTMF dialling will default to pulse dialling after 2 unsuccessful DTMF dialling attempts.

[13] 2nd System Option Code

Use the same method of programming as Section [12].

ZONE LIGHT

- [1] • ON = Call 1st phone number only
OFF = Call 1st phone number with back-up to 2nd phone number
- [2] ON = Master Code not user changeable
• OFF = Master Code user changeable
- [3] ON = Bell squawk enabled*
• OFF = Bell squawk disabled
- [4] ON = PC16OUT module enabled
• OFF = PC16OUT module disabled
- [5] ON = 6th code is "maid's code" (one-time use)
• OFF = 6th code is normal access code
- [6] ON = 1400 Hz handshake for Radionics formats # 3, 4, B and C
• OFF = 2300 Hz handshake for Radionics formats # 3, 4, B and C
- Factory default settings
- * With bell squawk enabled, the bell / siren will sound one short burst on arming and two short bursts on disarming.

NOTE: When the panel is set for Auto-Arming, the bell / siren will sound 1 short burst every 10 seconds for one minute before the panel Auto-Arms unless the 'Bell During Auto-Arm' is disabled (Section [32], light 2).

[14] 3rd System Option Code

Use the same programming method as in Section [12]

ZONE LIGHT

- [1] ON = Access code required for bypass
• OFF = Access code not required for bypass
- [2] ON = Enable [*][4] downloading call feature
• OFF = Disable [*][4] call feature¹
- [3] ON = Periodic downloading²
• OFF = Periodic test transmission
- [4] ON = [*][4] requires a access code
• OFF = [*][4] does not require access code
- [5] • ON = [P]anic key has keypad-audible feedback
OFF = [P]anic key without keypad-audible feedback
- [6] ON = Partial closings identified³
• OFF = Partial closings not identified
- Factory default settings

¹ The [*][4] command can be enabled so that by using this command the user or on-site installer can initiate a call to the downloading computer.

² The panel can be enabled to periodically call the downloading computer. The cycle time (in days) for the call is set in Section [19]. The automatic call to the downloading computer can be used to update the panel program and/or to upload status information from the panel.

³ If partial closings are enabled as identified, then alarm codes for the bypassed zones will be transmitted.

[15] Communication Variables

Once this section is entered, two 2-digit numbers are expected. Do not press the [#] key while entering data. The first 2-digit number defines the number of attempts (alarm and restoral pairs) per zone that the communicator will make before it shuts down for that zone (swinger shutdown). The number of attempts is for the period as defined in the 1st System Option Code Section, zone light 2. The number of attempts may be programmed from '00' to '99', where '00' means the communicator will never shut down. The fire zone cannot be shut down - it always transmits.

The second 2-digit number defines the delay before transmission. The delay is for zones defined as burglary zones only. 24 hour zones or the fire zone will not be delayed. The time may be programmed from '00' to '99' seconds, where '00' means no delay.

NOTE: For UL installations, the Maximum Transmissions section cannot be enabled. Also, the Delay Before Transmission must not exceed 15 seconds.

[16] Zone Bypass Mask

Use the same method of programming as used in Section [12]. If the zone light is ON, the zone can be bypassed; if OFF, the zone cannot be bypassed using the [*][1] command. The fire zone cannot be bypassed.

[17] System Times

There are 6 system times which can be programmed in this section, and each entry requires a 3-digit number. Do not press the [#] key during data entry.

[1] **Entry delay time** (001 to 255 seconds) This value determines the standard Entry Delay time. The factory default entry time is 30 seconds. See Section [11] for zone definitions.

[2] **Exit delay time** (001 to 255 seconds) This value determines the standard Exit Delay time. The factory default exit time is 120 seconds. For zone definitions, see Section [11].

[3] **Bell cut-off time** (001 to 255 minutes) This value determines the time the bell / siren will sound before automatically turning off. The factory default bell cut-off time is 4 minutes.

[4] **AC fail transmission delay** (001 to 255 minutes) This value determines the length of time before the communicator will transmit an AC failure report. The factory default time is 30 minutes.

[5] **"Slow" zone response time** (001 to 255 × 10 ms) This value determines the "slow" zone response time and provides times from 10 ms to 2550 ms. The factory default "slow" zone response time is 500 ms. NOTE: The "fast" zone response time is fixed at 10 ms. See Section [11] Zone Definitions.

[6] **Test transmission cycle time** (001 to 255 days) This value determines the frequency, in days, of the test transmission either via the communicator or by calling the downloading computer. The factory default setting is 30 days. See Section [14] 3rd System Option Code, light 3.

[18] Auxiliary Delay Zone Entry / Exit Times

This section requires two 3-digit entries to establish the Auxiliary Entry and Exit Delay times. Do not press the [#] key during data entry. The default Entry Delay is 45 seconds and may be changed to any time from 001 seconds to 255 seconds. The default Exit Delay is 120 seconds and may be changed to any time between 001 to 255 seconds.

For auxiliary delay zone times to be effective, the zone must be programmed as a type [7] in the Zone Definition Section [11].

[19] System Clock Times

This section requires two 4-digit entries to set the Automatic Arming Time of Day and the Test Transmission Time of Day. Do not press the [#] key during data entry. Factory default for both these times is '9999'; that is, NO automatic arming or test transmission will take place even if those functions are enabled. VALID times must be entered in this section before these features will function.

The system clock is in military time. Two digits from '00' to '23' are entered for the hour of the day and two digits from '00' to '59' are entered for the minute of the hour.

Test transmission or periodic downloading is selected in Section [14] 3rd System Option Code, Light 3. The cycle time in days for the test transmission or periodic downloading is set in Section [17] System Times. For a test transmission using the communicator, an automatic test code should be entered in Section [10]. For periodic downloading or a test transmission using the communicator, a valid transmission time must be entered in Section [19].

NOTE: Upon power-up, if either the Auto-Arm or the test transmission time has a valid time entered, then a loss-of-time trouble for the system clock will be initiated. Enter [*][2] to view the trouble. Light 6 will be ON. If neither the Auto-Arm or test transmission has a valid time, then the setting of the system clock does not matter.

[20] New Installer's Code

[21] New Master Code

[22] 2nd Master Code

Once the section number has been entered ([20], [21] or [22]), enter a new 4-digit code. Only use digits 0 through 9 as code numbers. Do not press the [*] or [#] keys. If an error is made entering the code, complete entry of the 4 digits then enter the section number again to enter the correct code. Do not press [*] or [#] while entering the code.

[23] Communication Formats

This section sets the type of format which will be sent to each of the two telephone numbers programmed in Section [01] and [03]. For each telephone number, enter one digit from the list below. See the HEX data programming section for details on how to enter digits 'A' through 'F'.

The selection for each phone number is determined by the type of receiver being called. Enter the format number for the 1st telephone number first. It is necessary to program both telephone format numbers even if the first phone number is

the only one being used.

- [0] SILENT KNIGHT / ADEMCO SLOW 10 BPS
(1400 Hz handshake)
3/1, 4/1 and 4/2 non-extended formats
- [1] SESCOA, FRANKLIN, DCI, VERTEX 20 BPS
(2300 Hz handshake)
3/1, 4/1 and 4/2 non-extended formats
- [2] SILENT KNIGHT FAST 20 BPS
(1400 Hz handshake)
3/1, 4/1 and 4/2 non extended formats
- [3] RADIONICS
(2300/1400 Hz handshake*)
3/1, 4/2 non extended formats
- [4] RADIONICS
(2300/1400 Hz handshake)
3/1, 4/2 non-extended with parity format
- [5] DO NOT USE
- [6] DO NOT USE
- [7] DO NOT USE
- [8] SILENT KNIGHT, ADEMCO SLOW 10 BPS
(1400 Hz handshake)
3/1 extended format
- [9] SESCOA, FRANKLIN, DCI, VERTEX 20 BPS
(2300 Hz handshake)
3/1 extended format
- [A] SILENT KNIGHT FAST 20 BPS
(1400 Hz handshake)
3/1 extended format
- [B] RADIONICS
(2300 / 1400 Hz handshake*)
3/1 extended format
- [C] RADIONICS
(2300 / 1400 Hz handshake*)
3/1 extended with parity format
- [D] DO NOT USE
- [E] DO NOT USE
- [F] DO NOT USE

* See Section [13] for Radionics handshake option.

10 BPS and 20 BPS Formats

10 BPS is the standard slow format used on Silent Knight / Ademco receivers. DATA = 1900 Hz; KISSOFF = 1400 Hz; SPEED = 10 baud

20 BPS is the standard fast format used on the DCI / Franklin / SESCOA and Vertex receivers. DATA = 1800 Hz; KISSOFF = 2300 Hz; SPEED = 20 baud

Radionics Format

For conventional Radionics 3/1 format, the communications mode should be set on either Radionics rounds [B] or Radionics parity [C]. The extended version of the Radionics format is normally used. The following guidelines are provided to help in configuring the PC1500 for Radionics format.

1. The customer account code must be only 3 digits with a zero making up the 4th digit (i.e. Enter 1230 to program an account code of 123).

2. The zone alarm reporting codes must all be single digit numerical codes with no extended 2nd round being sent (i.e. Zone 1 = 10, Zone 2 = 20... Zone 6 = 60). The zero in the 2nd digit position tells the PC1500 not to send an extended round.
3. All other non-alarm reporting codes must be set up to send an extended 2nd round. The 1st digit of the reporting code is used to identify the event while the 2nd or extended digit is used to associate the event with a particular item (i.e. A reporting code of E3 means restore zone 3. E = restore, 3 = zone 3).
4. The following is a list of 1st digit identifiers that should be used with the Radionics format.
 - Restorals "E"
i.e. E3 = restore zone 3
 - Openings "B"
i.e. B2 = opening by user 2
 - Closings "C"
i.e. C4 = closing by user 4
 - Troubles "F"
i.e. F5 = trouble from source 5
 - Miscellaneous "D"
i.e. D1 = partial closing

[24] Programmable Output Options (PGM Terminal)

The PGM output can be programmed in this section to operate in response to various panel operations. The output pulse connects the PGM terminal to the negative power rail.

[01] Ground Start Pulse

This option provides a 2-second output pulse before dialling begins to obtain the dial tone on Ground Start telephone equipment.

[02] Utility Output, no Access Code

When activated by entering the [*][7] command, the PGM output will go low for 5 seconds and the keypad buzzer will sound.

[03] Utility Output, any Access Code

The same as [02], except the command is [*][7] [any valid access code].

[04] 5-Second Reset Pulse

When this option is selected, the PGM output is normally low. That is, it is just the reverse of all other options which are normally high and go low when activated. This option is normally used as the negative return for power to 4-wire smoke detectors (positive comes from the AUX + terminal). To activate this output (to reset smoke detectors), enter the [*][7] command. The PGM terminal will go high (open circuit), and thus remove power from the devices connected. The keypad buzzer will sound for the 5-second period.

[05] Courtesy Pulse

This option provides an output which follows the Entry and Exit Delays. It can be used to turn on a courtesy light near the exit door for the duration of the Entry/Exit Delays.

[06] Keypad Buzzer Follow Mode

The PGM output will go low as long as the keypad buzzer is ON for "24 Hour Buzzer Zone", "Door Chime", "Entry Delay" and "Auto-Arm Alert".

[07] System Status (Armed / Disarmed)

The PGM output switches to and remains at ground as long as the panel is armed. The output goes high (open) while the panel is disarmed.

[08] Strobe Output (Latched Alarm Output)

The PGM switches to ground on an alarm and remains low until the panel is disarmed. It can be used to indicate that an alarm has occurred before entering the premises.

[09] Failure to Communicate

The PGM output switches to ground if the systems fails to communicate after 8 attempts to each phone number that will be tried according to the communicator call direction options. The output remains low until a successful communication takes place or until trouble #4 is cleared from the keypad. This option can be used to tie two systems together so that if one fails to communicate, the other system will report the failure.

[0A] PGM ON during Entry Delay

The PGM output will be switched on for the duration of the Entry Delay. This option may be used to provide lighting in the entrance area, or to activate a device when the Entry Delay begins.

[0B] PGM ON during Exit Delay

The PGM output will be switched on for the duration of the Exit Delay. This option may be used to provide lighting in the exit area, or to activate a device when the Exit Delay begins.

[25] Communicator Call Direction

This section requires four single digit entries using digits 0 to 3 only. This section defines how the communicator will call the telephone numbers programmed in sections [01] and [03] to report the following events:

- Zone Alarms and Restorals
- Access Codes Openings and Closings
- Priority Alarms and Restorals
- Maintenance Alarms and Restorals

Enter **one** digit from the list below for each of the above categories. Factory default = 1 for all 4 code groups.

- [0] Disables the function (no transmission for the group)
- [1] Call 1st phone number and back-up to the 2nd phone number when Section [13] light 1 is set to OFF and the panel has made 8 unsuccessful tries on the 1st phone number.
- [2] Call the 2nd phone number only
- [3] Always call both phone numbers

If the [#] key is pressed during data entry, you will be returned to the installer's programming mode and data for this section will **not** be saved.

[26] Downloading Telephone Number

This telephone number is used by the panel to call the downloading computer when a request to call is made by entering [*][4] or for an auto-download. See Section [14] 3rd System Option Code, lights 2 and 3. See Section [01] 1st Phone Number for instructions on programming the downloading telephone number.

[27] Downloading Access Code

This 4-digit code allows the panel to confirm that it is communicating with a valid downloading computer. Enter 4 digits using the numbers 0 through 9 only. The factory default code is [1515].

[28] Panel Identification Code

This 4-digit code allows the downloading computer to confirm the identity of the control panel. Enter 4 digits using the number keys 0 through 9 only. The factory default code is [1501].

[29] For Future Use

[30] Reset to Factory Default Software

Entering [30] will perform a software reset to the factory default values. Once this command is entered, the keypad buzzer will beep several times. The "Trouble" LED will be ON during the reset sequence.

Hardware

If the installer's code is forgotten and a software reset cannot be performed, the panel can be reset to the factory default values with the following method.

1. Remove all power, AC and battery, from the panel.
2. Short the pads on the panel labelled EEPROM RESET.
3. While maintaining the short, power-up the panel and wait for at least 10 seconds before removing the short.
4. Upon removal of the short, the keypad buzzer will beep and the panel will be reset to the factory default values.

[31] 4th System Option Code

Use the same programming method as in Section [12].

ZONE LIGHT

- [1] • OFF = **For future use**
 - [2] • OFF = **For future use**
 - [3] • OFF = **For future use**
 - [4] ON = Show bypass status while armed or disarmed
 - OFF = Show bypass status while disarmed only
 - [5] ON = Set for AC = 50 Hz
 - OFF = Set for AC = 60 Hz
 - [6] ON = Restore on bell time-out (if zone is restored)
 - OFF = Restore as follower (when zone restores)
- Factory default

[32] 5th System Option Code

Use the same programming method as in Section [12].

ZONE LIGHT

- [1] ON = Loss of AC will not cause an AC trouble
 - OFF = Loss of AC will cause AC trouble
 - [2] ON = No bell during Auto-Arm (burst every 10 seconds is silenced)
 - OFF = 1 burst of bell / siren every 10 seconds during Auto-Arm pre-alert
 - [3] • ON = Home-Away zones will have an entry delay when tripped
 - OFF = Home-Away zones act as interior when tripped
 - [4] ON = Quick-Exit is enabled ([*][0] ignores 1 transition of a delay zone)
 - OFF = Quick-Exit is disabled
 - [5] ON = Auxiliary delay zones can be force armed
 - OFF = Auxiliary delay zones cannot be force armed
 - [6] • ON = All zones except fire will be bypassed for 60 seconds upon power-up
 - OFF = All zones are active upon power-up
- Factory default

[33] For Future Use

[34] 6th System Option Code

Use the same programming method as in Section [12].

ZONE LIGHT

- [1] ON = Audible Exit Delay with urgency
 - OFF = Standard Exit Delay
 - [2] ON = Bell Squawk during Exit Delay
 - OFF = No Bell Squawk during Exit Delay
 - [3] ON = Audible Exit Fault enabled
 - OFF = Audible Exit Fault disabled
 - [4] ON = Urgency applied to Entry Delay
 - OFF = Standard Entry Delay
 - [5] ON = Bell Squawk during Entry Delay
 - OFF = No Bell Squawk during Entry Delay
 - [6] ON = [F] Key disabled
 - OFF = [F] Key enabled
- Factory default

When Light 3 is ON (Audible Exit Fault): When the system is armed and a Standard Delay Zone is left open at the end of the Exit Delay, the bell/siren will sound a steady tone for the duration of the Entry Delay.

Entry and Exit Delay Urgency: When the urgency option is selected for the audible Entry Delay, the keypad will sound a constant tone during the Entry Delay. During the last 10 seconds of the Entry Delay, the keypad will sound a pulsing tone to warn that the delay is about to expire.

When the urgency option is selected for the audible Exit Delay, the keypad will sound a pulsing tone during the Exit Delay. During the last 10 seconds of the Exit Delay, the keypad will sound a faster pulsing tone to warn that the delay is about to expire.

[35] For Future Use

[36] Keypad Lockout Control

Program two 2-digit numbers in this section.

The first entry determines how many invalid codes may be entered before the keypad is locked out and will not accept any further entries. Program a number from 00 to 99; 00 disables the keypad lockout function.

The second entry determines how long, in minutes, the keypad will be locked out once the programmed number of invalid codes are entered. Program a time from 00 to 99 minutes.

[90] Installer's Lockout Enable

This feature is enabled by entering [90] while in the installer's programming mode. A factory default (hardware or software) will not reset the installer's code or the download access code once this feature is enabled. A panel that has this feature enabled will give a distinct audible indication upon power-up. This indication is the phone line relay clicking 10 times. Make sure that your new installer's code has been entered correctly before enabling this feature because there is no way of re-entering the programming mode without the new installer's code. Remember that even a reset to the factory default will not change the installer's code back to the default.

[91] Installer's Lockout Disable

Entering [91] when in the installer's programming mode will disable the installer's lockout feature.

NOTE: Panels returned to DSC with the installer's lockout feature enabled and no other apparent problems will be subject to an additional service charge.

FOR THE RECORD

Customer _____

Address _____

Phone _____ **Installation Date** _____

CONTACTS:

#1 Name _____ Phone _____

#2 Name _____ Phone _____

#3 Name _____ Phone _____

Installer's Code _____

ZONES

Zone	Type	Protected Area
------	------	----------------

1 _____

2 _____

5 _____

Entry Time _____ Exit Time _____

Bell Cutoff _____

KEYPAD ZONES

[F] Key ☐ ON ☐ OFF

Quick-Arm ☐ ON ☐ OFF

[A] Key ☐ ON ☐ OFF

Quick-Exit ☐ ON ☐ OFF

[P] Key ☐ ON ☐ OFF

Installers Lockout ☐ ON ☐ OFF

Installer's Name: _____

NOTES

[illegible]

NOTE: In sections [01] to [10], do not enter data into sections that are not used.

[01] 1st Phone Number *Page 11*

Enter [0] for the digit 0 in the phone number. Enter [*4*] (HEX D) for additional dial tone detection between number digits, as in local PBX systems. Enter [#] to end the phone number entry

[02] 1st Account Code *Page 11*

Enter [*1*] (HEX A) for the digit "0" in the account code. For a 3-digit code, enter [0] for the 4th digit.

[03] 2nd Phone Number *Page 11*

NOTE: For UL installations, the second phone number must not be activated, as the total number of dialing attempts will be greater than 10.

[04] 2nd Account Code *Page 11*

[05] Zone Alarm Reporting Codes *Page 11*

For single digit reporting codes, enter [0] as the second digit. Enter [*1*] (HEX A) to transmit a "0" (zero = 10 pulses)

____ Zone 1 Alarm

____ Zone 2 Alarm

____ Zone 3 Alarm

____ Zone 4 Alarm

____ Zone 5 Alarm

____ Zone 6 Alarm

[06] Zone Restoral Reporting Codes *Page 11*

For single digit reporting codes, enter [0] as the second digit. Enter [*1*] (HEX A) to transmit a "0" (zero = 10 pulses)

____ Zone 1 Restoral

____ Zone 2 Restoral

____ Zone 3 Restoral

____ Zone 4 Restoral

____ Zone 5 Restoral

____ Zone 6 Restoral

[07] Closing (Arming) Reporting Codes / Partial Closing Reporting Code *Page 12*

- ☐ Access Code 1
- ☐ Access Code 2
- ☐ Access Code 3
- ☐ Access Code 4
- ☐ Access Code 5
- ☐ Access Code 6
- ☐ Partial Closing Code

[08] Opening (Disarming) Reporting Codes / After Alarm Reporting Code *Page 12*

The "after alarm" code is sent on disarming if an alarm occurred during the previous armed period.

- ☐ Access Code 1
- ☐ Access Code 2
- ☐ Access Code 3
- ☐ Access Code 4
- ☐ Access Code 5
- ☐ Access Code 6
- ☐ After Alarm Code

[09] Priority Alarms and Restorals *Page 12*

Actuation of the [F], [A] or [P] keys will immediately transmit both an alarm and restoral code. There is no delay on the restoral code transmission.

- ☐ Fire Zone Trouble
- ☐ Keypad [P]anic Alarm
- ☐ Keypad [F]ire Alarm
- ☐ Keypad [A]uxiliary Alarm
- ☐ Fire Zone Trouble Restore
- ☐ Keypad [P]anic Restore
- ☐ Keypad [F]ire Restore
- ☐ Keypad [A]uxiliary Restore

[10] Maintenance Alarms and Restorals *Page 12*

For automatic test code reporting, time between reports (in days) must be specified in Section [17], and time of day for the report must be entered in Section [19].

NOTE: For UL installations, either AC failure or battery trouble reporting must be enabled.

☐ Low Battery Alarm

☐ AC Fail Alarm

☐ Fuse Failure Alarm

☐ Low Battery Restore

☐ AC Fail Restore

☐ Fuse Failure Restore

☐ Automatic Test Code

[11] Zone Definitions *Page 12*

NOTE: When defining zones, assign delay zones first to zones 1,2,3... then assign the other types to the remaining zones in any order desired.

Default			First Digit	Second Digit
<u>0</u> <u>0</u>	<input type="checkbox"/>	Zone 1	0 = Slow, Audible	0 = Standard Delay
<u>0</u> <u>1</u>	<input type="checkbox"/>	Zone 2	1 = Slow, Silent	1 = Instant
<u>0</u> <u>1</u>	<input type="checkbox"/>	Zone 3	2 = Fast, Audible	2 = Interior
<u>0</u> <u>2</u>	<input type="checkbox"/>	Zone 4	3 = Fast, Silent	3 = Interior, Home-away
<u>0</u> <u>2</u>	<input type="checkbox"/>	Zone 5		4 = 24 Hour Bell
<u>0</u> <u>8</u>	<input type="checkbox"/>	Zone 6		5 = 24 Hour Bell/Buzzer
				6 = 24 Hour Buzzer
				7 = Aux. Delay (Uses Aux. Entry/Exit Delays)
				8 = Fire *

* Any **one** zone may be set as a FIRE zone.

[12] 1st System Option Code *Page 13*

Default			Zone Light ON	Zone Light OFF
<u>OFF</u>	<input type="checkbox"/>	Zone Light 1	Communicator disabled	Communicator enabled
<u>OFF</u>	<input type="checkbox"/>	Zone Light 2	TX limit to 24 hour period	TX limit to armed period
<u>ON</u>	<input type="checkbox"/>	Zone Light 3	Alarm display while armed	No alarm display while armed
<u>ON</u>	<input type="checkbox"/>	Zone Light 4	DTMF dialling	Pulse dialling
<u>OFF</u>	<input type="checkbox"/>	Zone Light 5	N.C. zones (except fire)	EOL resistor zones
<u>ON</u>	<input type="checkbox"/>	Zone Light 6	Keypad [P]anic audible (bell)	Keypad [P]anic silent (bell)

[13] 2nd System Option Code *Page 14*

Default			Zone Light ON	Zone Light OFF
<u>ON</u>	<input type="checkbox"/>	Zone Light 1	Call 1st phone only	Backup to 2nd phone ¹
<u>OFF</u>	<input type="checkbox"/>	Zone Light 2	Master Code not changeable	Master Code changeable
<u>OFF</u>	<input type="checkbox"/>	Zone Light 3	Bell Squawk enabled ²	Bell Squawk disabled
<u>OFF</u>	<input type="checkbox"/>	Zone Light 4	PC16 OUT enabled	PC16 OUT disabled
<u>OFF</u>	<input type="checkbox"/>	Zone Light 5	6th code is maid's code	6th code normal
<u>OFF</u>	<input type="checkbox"/>	Zone Light 6	1400 Hz Radionics	2300 Hz Radionics

¹ Do not program "OFF" unless 2nd phone number is programmed.

² With Bell Squawk enabled, the bell/siren will sound one short burst on arming and two short bursts on disarming.

[14] 3rd System Option Code *Page 14*

Default			Zone Light ON	Zone Light OFF
<u>OFF</u>	<input type="checkbox"/>	Zone Light 1	User code required for bypass	Code not required
<u>OFF</u>	<input type="checkbox"/>	Zone Light 2	[*] [4] Enabled	[*] [4] Disabled
<u>OFF</u>	<input type="checkbox"/>	Zone Light 3	Periodic downloading	Periodic test transmit
<u>OFF</u>	<input type="checkbox"/>	Zone Light 4	[*] [4] access code required	[*] [4] no code required
<u>ON</u>	<input type="checkbox"/>	Zone Light 5	[P]anic audible (buzzer)	[P]anic silent
<u>OFF</u>	<input type="checkbox"/>	Zone Light 6	Partial closing identified	Not identified

[15] Communication Variables *Page 14*

NOTE: For UL installations, the Maximum Transmissions section cannot be enabled. Also, the delay before transmission must not exceed 15 seconds.

Default

0,3 ___ Maximum transmissions per burglary zone

Enter digits from "01" to "99" for number of transmissions per zone during the period as defined in Section [12], 1st System Option Code, Zone Light 2. "00" = unlimited transmissions per burglary zone; the Fire zone always transmits.

Default

0,0 ___ Delay before transmission (burglary zones only)

Enter a time from "01" to "99" seconds; "00" = no delay. Fire zone and 24-hour zone transmissions cannot be delayed. Transmission delay as programmed here is for burglary zones only.

[16] Zone Bypass Mask *Page 14*

If the zone light is ON, the zone can be bypassed using the [*][1] command. If a zone is defined as a fire zone, it cannot be bypassed.

Default

 ON Zone Light 1

 ON Zone Light 2

 ON Zone Light 3

 ON Zone Light 4

 ON Zone Light 5

 ON Zone Light 6

[17] System Times *Page 14***Default**

 0 3 0 Entry Delay (seconds)

 1 2 0 Exit Delay (seconds)

 0 0 4 Bell Cut-off (minutes)

 0 3 0 AC fail transmission delay (minutes)

 0 5 0 Slow zone response time (× 10 ms)

 0 3 0 Test transmission cycle or auto download cycle time (days)

Valid entries are "001" to "255"; do not enter "000".

[18] Auxiliary Delay Zone Entry/Exit Times *Page 15***Default**

 0 4 5 Entry Time (seconds)

 1 2 0 Exit Time (seconds)

Valid entries are "001" to "255".

[19] System Clock Times *Page 15***Default**

 9 9 9 9 Automatic Arming (time of day)

 9 9 9 9 Test transmission or auto download (time of day)

Enter 4 digits - "00" to "23" hours; "00" to "59" minutes. If not used, leave at default setting "9999".

[20] New Installer's Code *Page 15*

For Sections [20], [21] and [22]: Enter 4 digits from "0" to "9". Do not enter [*] or [#].

Default

 1 5 0 0

[21] New Master Code *Page 15**Default*

1, 2, 3, 4, _ _ _ _ _

[22] 2nd Master Code *Page 15*

The 2nd Master Code can be erased by entering [*1111]. AAAA = not programmed

Default

A, A, A, A, _ _ _ _ _

[23] Communication Formats *Page 15*

It is necessary to program the format for both numbers, even if the second telephone number is not used.

Default

1, _ 1st Telephone Number

1, _ 2nd Telephone Number

Enter one HEX digit from [0] to [F] for each phone number from the following list:

[0]	SILENT KNIGHT / ADEMCO SLOW 10 BPS	(1400 Hz handshake)	3/1, 4/1 and 4/2 non-extended formats
[1]	SESCOIA, FRANKLIN, DCI, VERTEX 20 BPS	(2300 Hz handshake)	3/1, 4/1 and 4/2 non-extended formats
[2]	SILENT KNIGHT FAST 20 BPS	(1400 Hz handshake)	3/1, 4/1 and 4/2 non extended formats
[3]	RADIONICS	(2300/1400 Hz handshake*)	3/1, 4/2 non extended formats
[4]	RADIONICS format	(2300/1400 Hz handshake)	3/1, 4/2 non-extended with parity format
[5]	DO NOT USE		
[6]	DO NOT USE		
[7]	DO NOT USE		
[8]	SILENT KNIGHT, ADEMCO SLOW 10 BPS	(1400 Hz handshake)	3/1 extended format
[9]	SESCOIA, FRANKLIN, DCI, VERTEX 20 BPS	(2300 Hz handshake)	3/1 extended format
[A]	SILENT KNIGHT FAST 20 BPS	(1400 Hz handshake)	3/1 extended format
[B]	RADIONICS	(2300 / 1400 Hz handshake*)	3/1 extended format
[C]	RADIONICS	(2300 / 1400 Hz handshake*)	3/1 extended with parity format
[D]	DO NOT USE		
[E]	DO NOT USE		
[F]	DO NOT USE		

* See Section [13] for Radionics handshake option.

[24] **Programmable Output Options (PGM Terminal)** *Page 16*

Enter 2 digits from "01" to "0C" only.

Default

0,4	Programmable Output	[01] Ground Start Pulse
		[02] Utility Output, No Access Code - 5 seconds [*] [7]
		[03] Utility Output, Any Access Code - 5 seconds [*] [7]
		[04] 5 Second Reset Pulse [*] [7]
		[05] Courtesy Pulse (follows entry/exit times)
		[06] Keypad Buzzer Follow Mode*
		[07] System Status (arm/disarm) Output
		[08] Strobe Output (latched alarm output)
		[09] Failure to Communicate Output - follows trouble #4
		[0A] PGM ON during Entry Delay
		[0B] PGM ON during Exit Delay
		*[06] Buzzer follows the Entry Delay, door chime, auto-arm alert period and 24 hour buzzer zone.

[25] Communicator Call Direction *Page 16*

This section must be programmed completely. Do not press [#] to exit until all entries are completed.

Default

<u>1</u>	<input type="checkbox"/>	Zone Alarms and Restorals
<u>1</u>	<input type="checkbox"/>	Access Code Openings and Closings
<u>1</u>	<input type="checkbox"/>	Priority Alarms and Restorals
<u>1</u>	<input type="checkbox"/>	Maintenance Alarms and Restorals

[0] No transmissions for this group.

[1] Call 1st number and backup to 2nd number.*

[2] Call 2nd phone number only.

[3] Always call both phone numbers.

*Section [13] Light 1 "OFF" and 2nd phone number must be programmed.

[26] **Downloading Telephone Number** *Page 17*

This telephone number is used by the panel to call the downloading computer either by the periodic download function or through the use of the [*] [4] command.

Enter [0] for the digit '0' in the phone number. Enter [*4*] (HEX D) for additional dial tone detection between number digits, as in local PBX systems. Enter [#] to end the phone number entry.

[27] **Downloading Access Code** *Page 17*

Default

A number line with 8 equal segments. The first four segments are labeled 1, 5, 1, 5. The next four segments are empty.

This code allows the panel to confirm that a valid downloading computer is requesting access to the panel.

[28] Panel Identification Code *Page 17***Default**

1, 5, 0, 1, _ _ _ _

This code confirms the panel's identity to the downloading computer.

[29] For Future Use *Page 17***[30] Reset To Factory Default** *Page 17***[31] 4th System Option Code** *Page 17***Default****Zone Light ON****Zone Light OFF**OFF ☐ Zone Light 1

For future use

OFF ☐ Zone Light 2

For future use

OFF ☐ Zone Light 3

For future use

OFF ☐ Zone Light 4

Show bypass status/armed*

Show bypass status/disarmed

OFF ☐ Zone Light 5

AC = 50 Hz

AC = 60 Hz

OFF ☐ Zone Light 6

Restore on bell time out

Restore as follower

* If zone light 4 is ON, bypass status will always be shown.

If zone light 4 is OFF, bypass status is shown only when the panel is disarmed.

[32] 5th System Option Code *Page 17***Default****Zone Light ON****Zone Light OFF**OFF ☐ Zone Light 1

AC excluded from trouble

AC included

OFF ☐ Zone Light 2

No bell during auto-arm

Bell during auto-arm

ON ☐ Zone Light 3

Home-away with delay

Home-away as interior

OFF ☐ Zone Light 4

Quick exit enabled

Quick exit disabled

OFF ☐ Zone Light 5

Force arm on auxiliary delay

Auxiliary delay normal

ON ☐ Zone Light 6

60 s bypass on power-up

Zones active on power up

[33] For Future Use *Page 17*

[34] 6th System Option Code *Page 17*

Default			Zone Light ON	Zone Light OFF
<u>OFF</u>	<u> </u>	Zone Light 1	Audible Exit Delay with Urgency	Standard Exit Delay
<u>OFF</u>	<u> </u>	Zone Light 2	Bell Squawk during Exit Delay	No Bell Squawk during Exit Delay
<u>OFF</u>	<u> </u>	Zone Light 3	Audible Exit Fault enabled	Audible Exit Fault disabled
<u>OFF</u>	<u> </u>	Zone Light 4	Urgency applied to Entry Delay	Standard Entry Delay
<u>OFF</u>	<u> </u>	Zone Light 5	Bell Squawk during Entry Delay	No Bell Squawk during Entry Delay
<u>OFF</u>	<u> </u>	Zone Light 6	[F] Key disabled	[F] Key enabled

[35] For Future Use *Page 18***[36] Keypad Lockout Control** *Page 18***Default**

00 Number of Invalid Codes before lockout


00 Lockout Duration (minutes)

Enter 2 2-digit numbers in the range of 00 to 99. Program the Number of Invalid Codes as "00" to disable the lockout feature.

[90] Installer's Lockout Enable *Page 18***[91] Installer's Lockout Disable** *Page 18***WARNING!**

Panels returned to DSC with the Installer's Lockout enabled and no other apparent problems will be subject to an additional service charge!

HOOKUP DIAGRAM



For fire alarm applications, it is mandatory to use one UL listed indoor signalling appliance with a minimum 85dB rating and current rating of 1 Amp or less. (WHELOCK model 34T-12-R rated 85dB(A) minimum for indoor residential applications).

Temperature Range: 0°C-47°C (32°F-120°F)

Maximum Humidity: 85% R.H.

This equipment is UL listed for limited energy installations per NEC article 760. Recognized limited energy cable should be used. Observe NEC wiring requirements and local codes as defined by the authority having jurisdiction.

Do not replace fuses with higher values than noted in this drawing.

Security detection devices that require power from control panel must be UL listed for the intended application and operate over the voltage range of 10.0 to 14.0 VDC. The DSC BRAVO series is a recommended UL listed motion detector.

LIMITED WARRANTY

Digital Security Controls Ltd. warrants that for a period of twelve months from the date of purchase, the product shall be free of defect in materials and workmanship under normal use and that in fulfillment of any breach of such warranty, Digital Security Controls Ltd. shall, at its option, repair or replace the defective equipment upon return of the equipment to its repair depot. This warranty applies only to defects in parts and workmanship and not to damage incurred in shipping or handling, or damage due to causes beyond the control of Digital Security Controls Ltd. such as lightning, excessive voltage, mechanical shock, water damage, or damage arising out of abuse, alteration or improper application of the equipment.

The foregoing warranty shall apply only to the original buyer, and is and shall be in lieu of any and all other warranties, whether expressed or implied and of all other obligations or

liabilities on the part of Digital Security Controls Ltd. This warranty contains the entire warranty. Digital Security Controls Ltd. neither assumes, nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product.

In no event shall Digital Security Controls Ltd. be liable for any direct, indirect or consequential damages, loss of anticipated profits, loss of time or any other losses incurred by the buyer in connection with the purchase, installation or operation or failure of this product.

WARNING: Digital Security Controls Ltd. recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.

FCC COMPLIANCE STATEMENT

CAUTION: Changes or modifications not expressly approved by Digital Security Controls Ltd. could void your authority to use this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

The user may find the following booklet prepared by the FCC useful: "How to Identify and Resolve Radio/Television Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402, Stock # 004-000-00345-4

Important Information

This equipment complies with Part 68 of the FCC Rules. On the side of this equipment is a label that contains, among other information, the FCC registration number of this equipment.

Notification to Telephone Company

Upon request, the customer shall notify the telephone company of the particular line to which the connection will be made, and provide the FCC registration number and the ringer equivalence of the protective circuit.

FCC Registration Number: F53CAN-61031-AL-E

Ringer Equivalence Number: 0.0B USOC Jack: RJ-31X

Telephone Connection Requirements

Except for the telephone company provided ringers, all connections to the telephone network shall be made through standard plugs and telephone company provided jacks, or equivalent, in such a manner as to allow for easy, immediate disconnection of the terminal equipment. Standard jacks shall be so arranged that, if the plug connected thereto is withdrawn, no interference to the

operation of the equipment at the customer's premises which remains connected to the telephone network shall occur by reason of such withdrawal.

Incidence of Harm

Should terminal equipment or protective circuitry cause harm to the telephone network, the telephone company shall, where practicable, notify the customer that temporary disconnection of service may be required; however, where prior notice is not practicable, the telephone company may temporarily discontinue service if such action is deemed reasonable in the circumstances. In the case of such temporary discontinuance, the telephone company shall promptly notify the customer and will be given the opportunity to correct the situation.

Additional Telephone Company Information

The security control panel must be properly connected to the telephone line with a USOC RJ-31X telephone jack.

The FCC prohibits customer-provided terminal equipment be connected to party lines or to be used in conjunction with coin telephone service. Inter-connect rules may vary from state to state.

Changes in Telephone Company Equipment of Facilities

The telephone company may make changes in its communications facilities, equipment, operations or procedures, where such actions are reasonably required and proper in its business. Should any such changes render the customer's terminal equipment incompatible with the telephone company facilities the customer shall be given adequate notice to the effect modifications to maintain uninterrupted service.

Ringer Equivalence Number (REN)

The REN is useful to determine the quantity of devices that you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most, but not all areas, the sum of the RENs of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices that you may connect to your line, you may want to contact your local telephone company.

Equipment Maintenance Facility

If you experience trouble with this telephone equipment, please contact the facility indicated below for information on obtaining service or repairs. The telephone company may ask that you disconnect this equipment from the network until the problem has been corrected or until you are sure that the equipment is not malfunctioning.

Digital Security Controls Ltd.

160 Washburn Street
Lockport, NY 14094

PC1500 V4.0 NOTICE OF SOFTWARE RELEASE

The PC1500 Version 4.0 Software incorporates several new features and changes. The most important additions are features designed to prevent false alarms caused by user error.

False Alarm Reduction Features

The following features have been added to reduce the number of false alarms caused by user error.

Section [17] System Times

System times now allow more than 4 minutes for the Entry or Exit delay to allow users more time to enter or leave the premises. The default setting for the Exit Delay is now 120 seconds.

Section [24] Programmable Output Options

Two new options - 0A and 0B - will activate the PGM Output for the Entry Delay and Exit Delay respectively. These new options may be used to activate warning devices to warn occupants on the premises that the security system is being armed or disarmed.

Section [34] 6th System Option Code

The new 6th System Option Code adds 5 new false alarm prevention features. Each feature is enabled by turning its Zone Light ON.

- | | |
|---------------------|--|
| Zone Light 1 | Audible Exit Delay with Urgency
The Keypad will sound a pulsing tone during the Exit Delay. The pulsing tone will quicken during the last 10 seconds of the Exit Delay to warn the delay is about to expire. |
| Zone Light 2 | Bell Squawk During Exit Delay
The bell/siren will squawk during the Exit Delay. If Zone Light 1 is on, the bell/siren squawk will quicken during the last 10 seconds of the Exit Delay. |
| Zone Light 3 | Audible Exit Fault
When enabled, the bell/siren will sound with a steady tone to warn the user that the system has been armed with a Delay Zone left open. |
| Zone Light 4 | Urgency Applied to Entry Delay
The Keypad sounder will sound a quick pulsing tone during the last 10 seconds of the Entry Delay to warn that the Entry Delay is about to expire. |
| Zone Light 5 | Bell Squawk During Entry Delay
The bell/siren will squawk during the Entry Delay. If Zone Light 4 is on, the bell/siren squawk will quicken during the last 10 seconds of the Entry Delay. |

Other Programming Changes and Additions

Programming Section [17] System Times

All System Times are now programmed with 3 digits.

Programming Section [32] 5th System Option Code

Zone Light 3 is now ON in the default setting, meaning that Home-Away Zones will have an Entry Delay.

Zone Light 6 is now ON in the default setting, meaning that all zones except for Fire Zones will be bypassed for 60 seconds when power is applied to the control panel

Programming Section [36] Keypad Lockout Control

This new Section allows the installer to determine how many invalid codes (from 00 to 99) may be entered before the keypad is locked out. Section [36] also determines how long the keypad will remain locked out (00 to 99 minutes) before resuming normal operation. When the keypad is locked out, the system will not accept attempts to key in an Access Code, although the [F], [A], and [P] keys will still function.

New Downloading Software

Downloading Software DLS-1 Version 5.3U must be used to upload and download with the new PC1500 v4.0 Software. Do not attempt to perform downloading/uploading functions with the DLS-1 v5.2U or earlier software.