

PROGRAMMING THE PC4000

The PC4000 incorporates a new method of programming not similar to any previous DSC panel. The new method uses a menu system to arrive at a program location before data may be entered.


Book 1 contains the programming flow charts for the PC4000. The charts are arranged in such a way as to allow you to quickly find any option and the path required to arrive at the program location. In addition you will be able to see other options also available to you in the program area.

Plain boxes are program areas and shaded boxes are menu selections.

Two methods may be used to select the different menu items to arrive at a program location. With the first, you may use the arrow keys (<>) to scroll through the menu items. When the desired item is displayed press the [*] key. The [*] key is used as an 'ENTER' or 'SELECT' key. The panel will then move you to the next set of options.

The other method incorporates a 'HOTKEY' system. Every menu and program item contains a one or two digit 'HOTKEY' entry. Simply press the number(s) in the menu or program box and the panel will automatically select the item for you. DO NOT PRESS THE [*] AFTER ENTERING THE 'HOTKEY' NUMBER. This second method is much quicker once you become familiar with it.

EXAMPLE: We wish to program the Exit Delay for Partition 4. The following is the flow chart located in Book 1.



Using the first method the arrow keys would have to be pressed many times to scroll to the various items followed by the [*] key to select the item. Twelve keystrokes would be required after entering Installer Programming providing no mistakes are made. The keystrokes required are as follows:

- [>], [*] to select PARTITION AREA
- [*] to select ADD/EDIT PAR
- [>], [>], [>], [*] to select to PARTITION 4
- [>], [>], [*] to select PARTITION TIMES
- [>], [*] to select EXIT DELAY

Using the second 'HOTKEY' method we require only 5 keystrokes:

- [1] to select PARTITION AREA
- [0] to select ADD/EDIT PAR
- [4] to select PARTITION 4
- [2] to select PARTITION TIMES
- [1] to select EXIT DELAY

With less keystrokes required, programming is quicker as there is less chance of an error occurring.

At any time you may press the [#] key to exit a section. ANY DATA ENTERED WILL BE CHANGED. THE [#] KEY IS NOT AN ABORT KEY! The [#] key can also be pressed to move you back to the previous menu. Pressing the [#] key several times will exit you from Installer Programming.

To make programming easier the INDEX at the back of Programming Manual includes the chart number beside every option as well as the page number for a description of the option.

Programming Toggle Options

Some program areas contain several toggle options which pertain to the menu item selected. Use the arrow keys (<>) to scroll through the various items. Press the [*] key to toggle between [Y]es and [N]o for each feature. Once all the toggle options have been programmed press the [#] key to save your changes and return to the previous menu.

Programming HEX Digits

Often HEX digits are required for a program item. When a HEX digit is required press the [*] key to enter the HEX menu. You may use the arrow keys to scroll through the HEX digits (A through F) and when the desired letter is displayed press the [*] key.

Another much quicker method for entering HEX digits is to, first, press the [*] key followed by the number corresponding to the HEX letter i.e. A = 1, B = 2, C = 3 and so on. The [*] key must be pressed before entering each HEX digit as the software returns you to decimal programming automatically after each entry.

EXAMPLE: To enter data 'ABCD' on a PC4000 you would enter:


[*], [1], [*], [2], [*], [3], [*], [4]

NOTE: The [*] key is required before every HEX digit entered.

USER FUNCTIONS PROGRAMMING FLOW CHARTS


Armed State

While the partition is armed, press the [*****] key to call up this menu.




Disarmed State

While the partition is disarmed, press the [*] key to call up this menu.



PROGRAMMING FLOW CHARTS




	Page
SYSTEM AREA (0)	
► INSTALLER OPT'S (00)	8
► LCD MESSAGES (01)	8
► CODE ASSIGNMENT (02)	8
► SYSTEM OPTIONS (03)	9
► DLS SECTION (04)	11
► COMMUNICATOR (05)	12
► SW/AUX OUTPUT (06)	16
► MAIN BELL OUTPUT (07)	16
► PGM OUTPUTS (08)	16
► RS-232 OPTIONS (09)	18
PARTITION AREA (1)	
► ADD/EDIT PAR (0)	20
► DELETE PARTITION (1)	20
► COPY PARTITION (2)	20
MODULE HARDWARE (2)	
► ENROLL MODULE (0)	22
► DELETE MODULE (1)	22
► CONFIRM MODULE (2)	22
EVENT BUFFER (3)	
► PAN ENTIRE BUFF (0)	23
DIAGNOSTICS (4)	
► DIAGNOSTICS (0)	24
► BINARY PROGRAM (1)	24
► MEMORIZE VBAT. (2)	24
► FACTORY DEFAULT (3)	24





System Area Index


	Page
SYSTEM AREA (0)	
► INSTALLER OPT'S (00)	8
► LCD MESSAGES (01)	8
► CODE ASSIGNMENT (02)	8
► SYSTEM OPTIONS (03)	9
► DLS SECTION (04)	11
► COMMUNICATOR (05)	
► MAIN ITEMS (0)	12
► COMMSTOGGLES (1)	13
► COMMSMISC (2)	14
► REPORTING CODES (3)	15
► SWAUX OUTPUT (06)	16
► MAIN BELL OUTPUT (07)	16
► PGM OUTPUTS (08)	
► MAIN PGM OUT (0)	16
► 4204 OPTIONS (1)	16
► 4216 OPTIONS (2)	16
► 4216 CUSTOM (3)	16
► PGMPULSETIMES (4)	16
► RS-232 OPTIONS (09)	18


SYSTEM AREA ▶ INSTALLER OPTS/LCD MESSAGES/CODE ASSIGNMENT






















SYSTEM AREA ▶ SW AUXOUTPUT/MAIN BELL OUTPUT/PGM OUTPUTS


SYSTEM AREA ▶ SW AUX OUTPUT




SYSTEM AREA ▶ MAIN BELL OUTPUT




SYSTEM AREA ▶ PGM OUTPUTS




PGM Diagram


SYSTEM AREA ▶ RS-232 OPTIONS





Partition Area Index



PARTITION AREA ▶ ADD/EDIT PAR ▶ PARTOGGLES/PARTITION TIMES







SYSTEM AREA (3) Scroll to desired option using the [<][>] keys and press [*].

EVENT BUFFER (3) ► **PRN ENTIRE BUFF** (0)

DIAGNOSTICS

SYSTEM AREA
(1)

Scroll to desired option using
the [<][>] keys and press [*].

DIAGNOSTICS
(4)

DIAGNOSTICS
(0)

See Appendix C for information.

The following menus are present for first minute after power up only.

BINARY PROGRAM
(1) ► ENTHEX ADDRESS


MEMORIZEVBAT
(2) ► SETVBAT = 13.65V
PRESS ANY KEY

FACTORYDEFAULT
(3) ► POWER SYSTEM
DOWN AND RESTART

APPENDIX A

List of Available ASCII Characters

032	Ø	ø	P	Þ	R	Þ	Ñ	Ø	P
033	!	!	A	Ã	Q	Ã	È	Ã	À
034	"	"	B	Ã	R	Ã	Ã	Ã	Ã
035	#	#	C	Ã	S	Ã	Ã	Ã	Ã
036	*	*	D	Ã	T	Ã	Ã	Ã	Ã
037	%	%	E	Ã	d	Ã	Ã	Ã	Ã
038	&	&	F	Ã	u	Ã	Ã	Ã	Ã
039	:	:	G	Ã	W	Ã	Ã	Ã	Ã
040	()	H	Ã	X	Ã	Ã	Ã	Ã
041))	I	Ã	Y	Ã	Ã	Ã	Ã
042	*	*	J	Ã	í	Ã	Ã	Ã	Ã
043	+	+	K	Ã	j	Ã	Ã	Ã	Ã
044	,	,	L	Ã	l	Ã	Ã	Ã	Ã
045	-	=	M	Ã	m	Ã	Ã	Ã	Ã
046	=	>	N	Ã	^	Ã	Ã	Ã	Ã
047	/	?	O	Ã	o	Ã	Ã	Ã	Ã
048	049	064	065	066	067	068	069	070	071
096	097	098	099	098	099	099	099	099	099
112	113	114	115	114	115	115	115	115	115
160	161	162	163	162	163	163	163	163	163
176	177	178	179	178	179	179	179	179	179
192	193	194	195	194	195	195	195	195	195
208	209	210	211	210	211	211	211	211	211
224	225	226	227	226	227	227	227	227	227
240	241	242	243	242	243	243	243	243	243
244	245	246	247	246	247	247	247	247	247
248	249	250	251	249	250	250	250	250	250
252	253	254	255	253	254	254	254	254	254



APPENDIX B

List of Available Library Words

000 "BLANK LABEL"	037 "CELLAR"	074 "ENTRANCE"	111 "JANITOR"
001 "1ST"	038 "CENTRE"	075 "ENTRY"	112 "KEY"
002 "2ND"	039 "CHAMBER"	076 "EXIT"	113 "KITCHEN"
003 "3RD"	040 "CHIMNEY"	077 "EXTERNAL"	114 "LAB"
004 "4TH"	041 "CHINA"	078 "FACTORY"	115 "LAUNDRY"
005 "5TH"	042 "CHUTE"	079 "FAMILY"	116 "LEFT"
006 "ACCESS"	043 "CLOSET"	080 "FENCE"	117 "LIFT"
007 "AMBULANCE"	044 "COLD"	081 "FIELD"	118 "LIGHT"
008 "APARTMENT"	045 "COMPUTER"	082 "FIRE"	119 "LINES"
009 "atrium"	046 "CONDO"	083 "FLOOD"	120 "LIQUOR"
010 "ATTIC"	047 "CONTACT"	084 "FLOOR"	121 "LIVING"
011 "BABY"	048 "COPIER"	085 "FOIL"	122 "LOBBY"
012 "BACK"	049 "CORRIDOR"	086 "FORCE"	123 "LOFT"
013 "BALCONY"	050 "CORNER"	087 "FOYER"	124 "LOOP"
014 "BAR"	051 "CRAWL"	088 "FRONT"	125 "LOT"
015 "BARN"	052 "DARK"	089 "FULL"	126 "LOW"
016 "BASEMENT"	053 "DECK"	090 "FURNACE"	127 "LUNCH"
017 "BATHROOM"	054 "DEN"	091 "FUSE"	128 "MACHINE"
018 "BAY"	055 "DESK"	092 "GARAGE"	129 "MAIL"
019 "BEAM"	056 "DETECTOR"	093 "GAS"	130 "MANAGER"
020 "BEDROOM"	057 "DEVICE"	094 "GATES"	131 "MASTER"
021 "BELL"	058 "DINING"	095 "GLASS"	132 "MEDICAL"
022 "BOILER"	059 "DISH"	096 "GROUP"	133 "MEETING"
023 "BOTTOM"	060 "DISPLAY"	097 "GUARD"	134 "MIDDLE"
024 "BOX"	061 "DOOR"	098 "GUEST"	135 "MODULE"
025 "BREAK"	062 "DOORBELL"	099 "GUNS"	136 "MOTION"
026 "BROKEN"	063 "DOWNSTAIRS"	100 "GYM"	137 "NE"
027 "BURGLARY"	064 "DRAWER"	101 "HALLWAY"	138 "NW"
028 "CABINET"	065 "DRIVEWAY"	102 "HEAT"	139 "NORTH"
029 "CAFE"	066 "DRY"	103 "HOSE"	140 "NURSERY"
030 "CAGE"	067 "DUCTS"	104 "HOT"	141 "OFFICE"
031 "CAMERA"	068 "DUPLEX"	105 "HOUSE"	142 "OUTSIDE"
032 "CARPORT"	069 "EAST"	106 "HUMIDITY"	143 "OVER"
033 "CASH"	070 "ELECTRIC"	107 "INNER"	144 "OVERFLOW"
034 "CASHIER"	071 "ELEVATOR"	108 "INSIDE"	145 "OVERHEAD"
035 "CEILING"	072 "EMPTY"	109 "INTERCOM"	146 "PAD"
036 "CELL"	073 "EMERGENCY"	110 "INTERNAL"	147 "PANEL"

NOTE: 000 is a blank label for the "2ND" word, and is 'Zone XXX' for the "1ST" word.

APPENDIX C

List of Diagnostics

E = Communication error

T = Tamper open

LV = Low voltage to module

Indicated #	For Future Use
Number	
1	
2	
3	
4	
5	
6	
7	
8	

Indicated Number	PC4400 RS-232 Module #
25	1
26	1
27	2
28	3
29	4
30	5
31	6
32	7
33	8
34	9
35	10
36	11
37	12
38	13
39	14
40	For future use 15
41	For future use 16

Indicated Number	PC4216 O/P Module #
42	1
43	2
44	3
45	4
46	5
47	6
48	7
49	8
50	9

Indicated Number	LCD-4500 Module #
9	1
10	2
11	3
12	4
13	5
14	6
15	7
16	8
17	9
18	10
19	11
20	12
21	13
22	14
23	15
24	16

Indicated Number	PC4204 O/P Module #
51	1
52	2
53	3
54	4
55	5
56	6
57	7
58	8
59	9
60	10
61	11
62	12
63	13
64	14
65	15
66	16

