

DSC

From Tyco Security Products

The Simplicity and Ease of a Connected Home



The 'All-in-One'

DSC TOUCH

Panel





Panel

The DSC Touch panel redefines “all-in-one” with a 7” TouchScreen, six communication radios and a built in camera. Running on Google’s Android OS, the DSC Touch is intuitive and easy to use for dealers and end users.

FEATURES

- 7” TouchScreen
- Android OS
- Panel camera
- 6 wireless radios built in (Wi-Fi, Cellular, Security R/F, Z-Wave, Image Sensor, Bluetooth)
- Dual-path connectivity with integrated Wi-Fi and Cellular
- Compatible with DSC 433Mhz One-way wireless
- Interactive services powered by Alarm.com
- Photo frame
- Software updates
- Home control (lights, locks, outlets, thermostat)
- Built in microphone
- Dedicated speaker for Two-Way Voice
- SD card slot
- Video tutorials and FAQs
- Dealer message center



DSC

May 28, 2015

SYSTEM READY - DISARMED

Thu - 10:59 AM



PRESS TO ARM



WEATHER



CAMERA



STATUS



HOME CONTROL



APPS



SETTINGS



HELP




CONTACT US





7" TouchScreen

The 7" TouchScreen is built on the Android platform, enabling innovative features like language localization, custom text-to-speech, and software upgrades over Wi-Fi.






DSCTOUCH

Camera

The DSC Touch's built in camera takes a photo upon disarm and on alarm events.






Access the DSC Touch panel from anywhere with the Alarm.com app for smartphones.

AVAILABLE FOR

- iPhone
- Android
- Blackberry
- Windows 7
- iPad
- Kindle



Compatible with:



DSC TOUCH

Smart Socket

Control and monitor energy usage.





WEATHER

- High/Lo temps & precipitation
- 4-day forecast

COLOR-CODED STATUS

- Ready ● Not ready

TOUCH ARMING

- Arm stay
- Arm away
- Quick exit
- Disarm
- Bypass sensors
- Entry delay
- Exit sounds

SD CARD SLOT

- Add photos
- Manual software update

SPEAKER #1

- Dedicated to panel
- Sounds & voices



STATUS APP

- Current system status
- System alerts
- Alarm events
- System history

SETTINGS

- Installation
- System settings
- User management
- About
- System tests

PANIC BUTTON

- Auxiliary, fire or police

HELP


- FAQs
- Video tutorials

BUILT-IN

- SIA rate
- UL 102

STATUS

- Armed



CAMERA

- Disarm photos
- Alarm photos

CAMERA APP

- View disarm photos
- View image sensor pics
- View alarm photos
- Future camera features access

SPEAKER #2

- Dedicated for two-way voice

APPS

- Photo frame
- Sound settings
- Bi-lingual toggle
- Safety sensors

CONTACT

- Dealer contact info
- Message center

3 ZONE SIREN

- 3 standard

MICROPHONE

- Built-in
- Two-way voice

HOME

- Return to Home screen

HOME CONTROL

- Smart Socket
- Locks
- Thermostat

DSC TOUCH

Tilt

Never forget to close it.





AT&T 95%

10:25

Monday, October 7

DSC Touch now
McLerran Family: The Garage Tilt
was left open at 10:25 am on
Monday, Oct 7.
slide to reply





Image Sensor

Peek-In Now.

Peek-In Next Motion Alarm events.

Affordable Surveillance –
Simple and Easy.








Door Locks

TouchScreen technology for the front door.



1 2 3
4 5 6
7 8 9
* 0 #



WS4949



WS4959



WS4938



WS4985



EV-DW4917



WLS912L-433



EV-DW4927SS



EV-DW4975



WS4926



WS4939



WS4904P



WLS914-433



WS4920



WS4945



WS4965



WS4916



WS4913



To order, contact your Order Entry Account Representative at 1-905-760-3000 or 1-888-888-7838 (Toll-free in USA and Canada). For more information on these or other DSC products, e-mail info@dsc.com or contact your local Sales Representative.



Connect to Wi-Fi

- Touch “Settings” and enter master code
- Touch “System Settings”
- Touch “Wireless Settings”
- Touch “Wi-Fi Settings”
- Select Wi-Fi network. (enter password if required)



Add Users

- Touch “Settings” and enter master code
- Touch “User Management” and then touch “Add User”
- Enter the new user’s name and code for the user
- Select the type of user and touch “Save”



Customize Sensor Names

- Touch “Settings” and enter master code
- Touch “Edit Sensors” then touch “pencil” button to edit
- Touch “Sensor Name” and choose “Custom Description”
- Touch the name field, and type the desired name
- Touch “Save”



Customize Photo Frame

Touch “Apps” and touch “Photo Frame”

1. Load photos onto an SD Card (*Images must be less than 1MB each and saved inside a folder named “DCIM” or “Photos”)
2. Insert the SD Card into the panel*
3. Open the “Photo Frame” app
4. Press “Load from SD Card”
5. Choose to “Replace” (deletes all existing photos and saves the new ones) or “Add” (adds new photos to the ones already stored on the panel)
6. Wait about 1 minute for the images to load before removing SD card
7. Once loaded, press “Start Photo Frame” to test.

**Do not insert SD Card into panel if power is off*

Stay Connected.

Configure Your Mobile Access

Login to your alarm.com account using the following credentials:


LOGIN

PASSWORD

Use these same login credentials to access your smartphone app and the web portal at alarm.com/login (*password can be changed online*)



Use the device to search for “Alarm.com”





For more information on products please call:
+1-905-760-3000 or Toll Free: 1-888-888-7838
Email: info@dsc.com or contact your
DSC Account Representative