

# UL Online Certifications Directory

[OCD Home](#) [Quick Guide](#) [Contact Us](#) [UL.com](#)

## UTOU.S4019

### Control Units and Accessories, Household System Type

[Page Bottom](#)

---

### Control Units and Accessories, Household System Type

[See General Information for Control Units and Accessories, Household System Type](#)

**DIGITAL SECURITY CONTROLS, DIV OF TYCO SAFETY PRODUCTS** S4019  
**CANADA LTD**

95 BRIDGELAND AVE  
NORTH YORK, ON M6A 1Y7 CANADA

**Combination control units**, Models PC4020 v3.1 and P-16128A are intended for use with other Listed devices as indicated in the Installation Instructions to form a combination fire, burglary and home health care warning system. Each control unit incorporates a digital alarm communicator transmitter.

**Combination control units**, Models P832, PC5010, -5015/P832DL, PC5020, P-8+, PC1555 PC-01, PC5010 PC-01, consisting of subassemblies and enclosures, for use with separately Listed devices as indicated in the installation instructions. Control unit has integral DACT.

**Combination household fire and burglary warning system control units**, Models P6B, P6BMX, PC5008, -1555, -1555MX, -1565, Power 632 for use with at least one Model LCD5500, -5500Z/P832-LCD2, -5501Z, -5511, P832-02Z, P832-ICON, P832-LCDZ, PC1555RKZ, -5008, -5502Z2, -5508Z/P832-082, PRS6RKZ; Model LED5511 keypad and other Listed devices as indicated in the installation wiring diagram and instructions.

**Combination household fire and burglary warning system control units**, Models PC4010, -4010CF, -4020, P/PC4020CF for use with at least one Model LCD-4500 keypad and other Listed devices as indicated in the installation wiring diagram and instructions.

**Combination system fire and burglary warning system control units**, Models P-6, P48, PC 580, -1550, -585, Power 432 all with Model RM-1 EOLR and at least one Model P832-02Z, PC -55002, -55062, RK6, PRS61, -6002 control unit accessory keypad. Each control unit contains an integral digital alarm communicator transmitter. For use with other separately Listed devices as indicated in the manufacturer's installation instructions to form a control unit system.

**Control unit accessories**, Models LCD-4500, -4501, -4501T, -4503Z, -4510, -4520, -4520T, -4521, -4521T, PEKP, PK5500, PK5501, PK5508, PK5516, RFK5500-433, RFK5501-433, RFK5508-433, RFK5516-433, PRS400, -400F, -400FT, -400T, SL -80 keypads. For use with separately Listed compatible control units as indicated in the installation instructions.

**Control unit accessories**, Models KP5508/16/32, may be suffixed by T, Z or TZ; KPL5500, LCD5500, LCD5501, LCD5520Z, NMF1008, P832-02Z, P832-08/16/32, may be suffixed by T, Z or TZ; P832-LCD, PC-1560RKZ, -5502Z2, PC5508/16/32, may be suffixed by T, Z or TZ for use with the Model PC5010 control unit.

**Control unit accessories**, Models AMA-100, AMB-300, -600, AMP-700, -701, -702, PAMA-100, PAMB-300, -600, PAMP-700, -701, PC5100 for use with the Model PC5010.

**Control unit accessories**, Models LCD5501Z32-900 keypad/receiver; Model PICON-900 keypad/receiver; Models LCD5501Z33-433, RF5501-433 keypad/receiver and RF5501-433NA keypad/receiver with RF; Model PICON-433 keypad/receiver.

**Control unit accessories**, Models PKP-ICN, PKP-LCD, PKP-400.

**Control unit accessories**, Model WLS-906 RF smoke detector, Model PWLS/WLS-909 key fob.

Model PWLS/WLS-910 handheld keypad.  
Intended for installation by experienced installer.

**Control unit accessories**, Model BSM-100, bell supervision module; Model AML-770X short circuit isolator, where the "X" is the letter A, B or C; Model AML-900 back box.

**Control unit assemblies**, Models P4108, P4108A, PC4108, -4108A, -4116 zone expanders; Models PC4204, PC4204CX, PC4204CXCF auxiliary relay/power supply module; Model PC4216 switched transistor output module.

**Control unit assemblies**, Models DLM-4 , PC5108D, -5108L/P5108L for use with the Model PC5010 control unit; Model ESCORT 4580 voice assisted security module, Model PC4936 audio interface module; Model PC4937 audio expansion module; Model P4580 voice assisted security module; Model P4936 audio interface module; Model P4937 audio expansion module.

**Control unit assembly**, Model PC4580 for use with Models P16128, PC4020, P/PC4020CF control units.

**Control unit assemblies**, Models PC4050C, -4056C , P4056C, P/PC4050CR.

**Control unit assembly**, Model PC4401/ serial interface module for use with Models P864(-CB,-CF,-CBCF), PC4010(-CF,-AR-CFAR), PC4020(-CF,-AR,-CFAR), P16128(-CF,-CB,-CBCF) control units.

**Control unit subassemblies**, Models HS-CAB1000, HS-CAB3000, HSCAB-4000 enclosures.

**Combination control unit**, Models NT9010-433, PNT9010-433, Envoy NT9010A0-433, PNT9010A-433 short range RF receivers are intended for use with other Listed devices as indicated in the Installation Instructions to form a combination household fire, burglary and home health care warning system. Each control unit incorporates a digital alarm communicator transmitter.

**Control unit accessories**, Model P/PC5132-433 radio receiver; Model P/PC4164-433 RF receiver, PC5320; Model RF5108-433 RF receiver, multiple wireless receiver module; Model RF5132-433 RF receiver. For use with other separately compatibly Listed devices as indicated in the manufacturer's installation instructions.

**Control unit accessories**, Models PNT9201, NT9201 remote sounder. For supplementary use only.

**Control unit assemblies**, Models PC5100/P5100, PC5108/P5108, PC5208/P5208.

**Control unit accessories**, Models PC5580/P5580, PC5580TC/P5580TC, PC5400/P5400, PC5204/P5207.

**Combination control unit**, Model PC5020CF, P-8+, for use with separately Listed devices as indicated in the installation instructions.

**Control unit assemblies**, Models PC5200, NT9204.

**Combination control unit**, Models NT9005-433, Envoy LCD, Advantage Triguard short range RF receivers are intended for use with other Listed devices as indicated in the Installation Instructions to form a combination household fire and burglary warning system. Each control unit incorporates a digital alarm communicator transmitter.

**Control unit subassemblies**, Models PC5020 (UA186), PC1555 PC-01 (UA186), PC5010 PC-01 (UA186), PC5700, for use with PC5020, P-8+, PC5020CF, P-8+CF, control units.

**Combination control unit subassemblies** , Models PC1616, PC1832, PC1864, intended for use with other Listed devices as indicated in the installation instructions to form a combination fire, burglary, and home health care warning system. Each control unit subassembly incorporates a digital alarm communicator transmitter.

**Combination household fire and burglary warning system Control Unit subassemblies**, Model AXT Terminal Expansion Module. The Model AXT is intended for use with the Model Security Gateway/GTW 5000 system.

**Household fire and burglary warning system control unit enclosure**, Model GTW5000/March Networks. For use with Model Security Gateway/GTW5000 System.

**Control unit accessories**, Model Skyroute CL3050 cellemetry communicator intended for use with separately Listed control units as indicated in the installation instructions.

**Control unit accessory** , Model GS3055-I GSM-GPRS Interface, GS3060 GSM-GPRS Interface. Intended for use as a primary (sole) communication means or as a back-up when used in conjunction with a POTS line (dialer) when used with separately Listed control units as indicated in the installation instructions.

Models PRM-2WC, PRM-4WC polarity reversal modules intended for use with separately Listed control units as indicated in the installation instructions.  
Models PRM-2W, PRM-2W polarity reversal modules intended for use with separately Listed control units as indicated in the installation instructions.  
Models RM-2 end-of-line relay module intended for use with separately Listed control units as indicated in the installation instructions.

**Control unit assemblies**, Models AMX-400, AMP-704 for use with separately Listed control panels as indicated in the installation instructions.

**Control unit enclosure**, Model AMP-704 enclosure.

**Control unit subassemblies**, Models T-Link , T-Link TL250 , T-Link TL300 ethernet communicator for use with separately Listed control unit as indicated in the installation instructions.

**Control unit** , Models SCW9047-433, SCW9045-433 short range low power RF and hardwire system.

[Last Updated](#) on 2008-04-04

---

®

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Listed and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Designs and/or Listings (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from Underwriters Laboratories Inc." must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "Copyright © 2008 Underwriters Laboratories Inc.®"

An independent organization working for a safer world with integrity, precision and knowledge.

