



ULC-LA


POWER INDICATOR
LIGHT ASSEMBLY

INSTALLATION INSTRUCTIONS

The ULC-LA provides a visual indication of AC power being supplied to the control panel for applications where this type of indication is required.

Installing the ULC-LA

- Remove one knockout from the position on the cabinet where the light assembly will be most visible.
- Run the wires through the knockout hole and press the assembly into the opening.
- Connect the leads as illustrated.



CAUTION: Route leads away from batteries, transformer and other wiring to reduce the possibility of shorting.



ULC-LA


POWER INDICATOR
LIGHT ASSEMBLY

INSTALLATION INSTRUCTIONS

The ULC-LA provides a visual indication of AC power being supplied to the control panel for applications where this type of indication is required.

Installing the ULC-LA

- Remove one knockout from the position on the cabinet where the light assembly will be most visible.
- Run the wires through the knockout hole and press the assembly into the opening.
- Connect the leads as illustrated.



CAUTION: Route leads away from batteries, transformer and other wiring to reduce the possibility of shorting.