

PowerSeries – Programming Custom Labels on LCD5500Z v3.0+ Keypads

Panels:

PC580 (Power432), PC1555 (Power632), PC5010 (Power832), PC5020 (Power864)

Overview:

Custom zone labels can be programmed on the LCD5500Z keypads, to make operation easier for the end user.

Programming LCD labels is a five-step process:

- Enter LCD programming
- Enter the label number
- Program the zone label
- Save the zone label
- Broadcast Labels to other LCD5500(Z) keypads

Step 1 – Enter LCD Programming

To get into LCD Programming, enter the following:

Enter [*][8][Installer's Code]
Press [*]

Enter Installer's Programming
Enter LCD Programming

Step 2 – Enter the Zone Label Section Number

To program in the Zone Label, enter the three-digit number corresponding to that zone.

LCD Sections [001] to [032]
LCD Sections [001] to [064]

Power432, Power632 and Power832
Power864

Step 3 – Program the Label

1. Use arrow keys (< >) to move the underline bar underneath the letter to be changed.
2. Press the number key [1] to [9] corresponding to the letter that is required. The first time that the number is pressed, the first letter will appear. Pressing the number key again will display the next letter, etc.

Refer to the following chart:

[1] – A, B, C, 1	[6] – P, Q, R, 6
[2] – D, E, F, 2	[7] – S, T, U, 7
[3] – G, H, I, 3	[8] – V, W, X, 8
[4] – J, K, L, 4	[9] – Y, Z, 9, 0
[5] – M, N, O	[0] – Space

3. When required letter or number is displayed on the keypad, use the arrow keys (< >) to scroll to the next letter.

Step 4 – Save the Label

Once the Label has been entered, it must be saved. Press the [*] key to access the menu. [Save] will be the first option. Press [*] to save the label.

Step 5 – Broadcast Labels

The programmed labels can be broadcasted to all the LCD5500(Z) keypads on the system. To broadcast labels, enter the following at the keypad that has the programmed labels:

Enter LCD Section [997]
Press [*]

Broadcast Label section
To begin the 'broadcast' label function

Depending on the number of LCD keypads present, the broadcast feature may take up to 1 minute to complete.

Technical Tips:

1. One LCD5500(Z) keypad must be assigned to slot 8 (default) for uploading/downloading functions.
2. If multiple LCD5500(Z) keypads are present, only one keypad should be assigned to slot 8.
3. After downloading changes are made, the keypad in slot #8 will automatically broadcast the changes to all other LCD5500(Z) keypads on the system.

Quick Test:

Access the Bypass menu in the [*] [1] menu. The zone labels will be displayed for the zones.