

# GS3055-I CF

---

Fire Alarm Communicator for central station service fire alarm - commercial  
RF communicator (GSM-GPRS network) signaling devices

## Installation Manual



---

***WARNING: This manual contains information on limitations regarding product use and function and information on the limitations as to liability of the manufacturer.***

---

# Table of Contents

Introduction .....	1
Features.....	1
Technical Specifications .....	1
Description .....	2
Approvals Information .....	2
Identification of Parts .....	3
Installation of GS3055-I CF .....	4
GS3055-I CF Connections Descriptions .....	5
Status LEDs .....	6
Operating Modes .....	7
Simulated Land Line (Dialer) Mode.....	7
Inputs Activation Mode .....	8
Outputs .....	8
Contact ID Events Description .....	8
Appendix - Wiring Diagrams .....	9

## Introduction

---

The GS3055-I CF is a wireless communicator for UL commercial fire and/or burglary applications. The GS3055-I CF can send status change events information over the GSM GPRS Network from the Alarm Control Panel at the protected premises to a supervising station. The device is compatible with UL listed alarm receiver Models SG-SYSTEM III (using SG-DRL3-IP line card), SG-SYSTEM II and SG-SYSTEM I.

This product is UL listed under requirements of UL864 9th Edition and UL1610 Standards as a Fire Alarm Communicator for central station service fire alarm – commercial and it can be installed in certified installations in accordance with the requirements of UL827 Standard and NFPA72 2002 (Section 8.5.4 Other Transmission Technologies), NFPA72 2007 (Section 8.6.4 Other Transmission Technologies) or NFPA72 2010 Code (Section 26.6.3.1).

## Features

---

- Compatible with listed alarm control panels that have an integrated DACT and support a 4 or 10-digit Contact ID Communication Format
- Complete solution CF Kit includes tamper protection output, listed power supply and battery standby capability for 24h
- Telephone line overvoltage protection and monitoring with automatic switch over to the GSM network communication path when a phone line trouble condition exists
- GSM network connection and signal strength indicator
- 4 Input lines and 4 Open collector outputs available for interfacing with the alarm control panel
- Internet/Intranet IP communication over the GSM GPRS network

## Technical Specifications

---

Input Voltage: ..... 120V/60HZ/0.3A  
Standby Voltage: ..... 12V/7Ah  
Standby Time: ..... 24h (NSC) plus 5 minutes alarm  
Standby Battery: ..... Sealed, rechargeable type, replace every 3-5 years  
Low Battery Trouble Indication Threshold: ..... 11.5Vdc  
Battery Deep Discharge Protection (cut-off) ..... 9.5Vdc  
Recharging Current: ..... 700mA (max.)  
Inputs: ..... 12V/1mA, 4 available, supervised  
Outputs: ..... 12V/50mA, 4 open-collector available, not supervised  
Loop Resistance: 1k ohm (max. loop resistance between devices connected in series on T1/R1)  
Operating Frequency: ..... 850/1900MHz (Dual Band GSM Radio)  
Antenna Gain: ..... 1.5dB (product shall be used only with the supplied antenna)  
Operating Temperature: ..... 0°C - 49°C (32°F - 120°F)  
Humidity: ..... 93%RH maximum (non-condensing)  
Metal Enclosure: red, with hardwired transformer and high voltage connection box included  
Dimensions: ..... 290mm x 254mm x 75mm (11-1/2" x 10" x 3")  
Weight: ..... 5.8Kg (12.8 lbs) (including standby battery)

*This equipment, GS3055-I CF, is fixed and shall be installed by Service Persons only (Service Person is defined as a person having the appropriate technical training and experience necessary to be aware of hazards to which that person may be exposed in performing a task and of measures to minimize the risks to that person or other persons) according to the local rules and regulations. It shall be installed and used within an environment that provides the pollution degree max 2, over voltages category II, in non-hazardous, indoor locations only. This manual shall be used with the Installation Manual of the alarm control panel. All instructions specified within that manual must be observed. **WARNING: The metal shell of the RS232 connector is not earthed! Before connecting to this port, check the metal shell for HAZARDOUS VOLTAGES!***

## Description

---

The GS3055-I CF has the capability of communicating alarm signals via the GPRS data network. This capability provides a fast, reliable path to central stations equipped with a Sur-Gard System III, System II, or SG-SYSTEM I receiver. By connecting a GS3055-I CF to a control panel's standard PSTN interface, telephone-based Contact ID signals are decoded and seamlessly routed through the GPRS network to any of the compatible receiver options.

**The performance of the GS3055-I CF depends greatly on GSM Network coverage; therefore, it should not be mounted without first performing placement tests to determine the best location for reception (minimum one green LED is ON). Optional antenna kits are available.**

**The GS3055-I CF requires enrollment with CONNECT 24 to operate. Dealer application forms and additional information on the CONNECT 24 Voice Response Unit (VRU) and web user-interface can be found at [www.connect24.com](http://www.connect24.com) or at the following telephone numbers:**

USA 1-888-251-7458

CANADA 1-888-955-5583

## Approvals Information

---

### For Commercial Fire Monitoring Installations:

The GS3055-I CF can be used in the following configurations:

1. Standalone communicator, single communication technology - 5 minute supervision (Heartbeat sent to supervising station every 97 seconds).
2. Back-up communicator line for a DACT (dual communication technology, no heartbeat sent).
  - Alarm signals must be sent first over the primary communication path (DACT) and then if this is known to have failed, over the secondary communication paths (Other transmission technologies)
    - Primary: Compatible Listed control unit's land line to central station (primary).
    - Secondary: GS3055-I CF transmission through GSM-GPRS network to central station.
  - Every 24 hours, a check-in signal must be sent to the central station over the primary dialer. The GS3055-I CF sends a heartbeat test transmission to the supervising station every 24 hours.
  - Each communication path shall be monitored for integrity (DACT shall have line monitoring enabled and GS3055-ICF shall have cellular connection supervision enabled).

### For UL Central Station Commercial Burglary Installations:


The GS3055-I CF can be used in the following configurations:

1. Standalone communicator, single line-200 second supervision (heartbeat sent to supervising station every 97 seconds. Alarm receiver supervision window set to 200 seconds).
2. Primary communicator line for a DACT (heartbeat sent to supervising station every 97 seconds. Alarm receiver supervision window set to 200s).
3. Back-up communicator line for a DACT (no heartbeat sent).

The GS3055-I CF is designed to work with the Contact ID communication format as described in SIA DC-05 Standard. Before completing the field installation of the alarm monitoring system, please ensure communication with the supervising central station is successful by sending several events and getting confirmation that they have been received.

Identification of Parts

The numbers in square brackets [ ] in this manual refer to the main parts of the GS3055-I CF (see Fig.1 below) described in this section.



**NOTES:** Connection of metal-clad cable, conduit, metal raceway or the like is permitted as a means for grounding. Use the supplied starwashers to secure the mains connection box cover and the front cover of the enclosure.

PARTS	
1	GS3055-I CF Metal Enclosure
2	External Antenna (supplied)
3	Antenna mounting hardware
4	GS3055-I CF PCB Assembly
5	GSM Radio with Connector for Antenna
6	SIM Card Socket
7	Status LEDs
8	Tamper Switch
9	GS3055-I CF Connections (see Fig. 2 for details)
10	Power Supply PCB Assembly
11	Power Supply Connections (see Fig. 3 for details)
12	Standby Battery Leads
13	Standby Battery 12V/7Ah
14	Transformer 16.5V/37VA
15	Mains Connections Box with Cover
16	13/32" GS3055-I Stand-offs (4)
17	11/32" Power Supply Stand-offs (4)

Figure 1 - Parts

## Installation of GS3055-I CF

---

### **CONNECT 24 Enrollment Information**

Only authorized dealers can enroll a GS3055-I CF with CONNECT 24. Dealer application forms and additional information on the CONNECT 24 Voice Response Unit can be found at the CONNECT 24 web site [www.connect24.com](http://www.connect24.com). Please contact CONNECT 24 at the number below for assistance:

USA 1-888-251-7458      CANADA 1-888-955-5583

**NOTE: Steps 1 and 2 should be completed before powering the GS3055-I CF unit.**

### **STEP 1 - Activate Your SIM Card**

Your SIM card must be activated with Connect 24 prior to use. **Please call the Voice Response Unit (VRU) at least 24 hours prior to installation at 1-866-910-3865.**

### **STEP 2 - Initialize the GS3055-I CF with Connect 24**

Call the VRU at the toll-free number. Follow the voice prompts and enter in your profile number, installer ID number, installer PIN number and central station number. Ensure all information is available before calling the VRU. All this information can be found in your VRU Enrollment Package.

**NOTE: For UL Commercial Fire listed products the supervision heartbeat shall be enabled.**

### **STEP 3 - Determine Best Signal Location**

1. Remove the screws and the front cover of the GS3055-I CF metal enclosure [1].
2. Fit the antenna [2] (ensure that the bolt [3] is fastened tightly).
3. Connect the antenna to the GSM Radio [5] and ensure the connector is secure.  
**NOTE: Before inserting or removing the SIM card, please ensure the unit is powered down.**
4. Ensure the SIM card is placed in its socket [6].
5. Power up the GS3055-I CF module [4] and check signal strength on status LEDs [7].
  - Use a DC power source rated 12V/0.7A connected to +/- 12V terminals [9]
  - Allow unit to power up
  - The green LEDs will indicate the signal strength. The bottom green LED must be ON for the location to be acceptable. Please refer to the "Status LEDs" section for more information.
6. Power down the GS3055-I CF by removing the DC power source.

### **STEP 4 - Connect the GS3055-I CF**

1. Using the cabinet, mark the 4 screw locations then drill the anchor screw holes.

**NOTE: Check for cable conduits and water pipes before drilling.**

2. Using anchor screws (not included), mount the cabinet to the wall.
3. Run the cables, then pull them through the cable entry or the knockouts provided.
4. Complete the connections to the terminal blocks [9], [11]. **Ensure power and Telco circuit connections are made only after the cabinet has been secured to the building or structure and has been connected to the protective earth ground.** Descriptions of the terminals can be found in the "Connecting the GS3055-I CF" section.
5. Using the 4 screws, reattach the front cover securely to the cabinet [1].

**NOTE: Please refer to Figures 2 and 3 at the end of this manual for wiring diagrams.**

**NOTE: When installing the GS3055-I CF in conjunction with a fire panel that has an integrated dual telephone line dialer (dual DACT), install only one of the telephone lines from the dual line dialer to the GS3055-ICF communicator. The second telephone line of the dual line dialer cannot be connected to the input of the GS3055-ICF and must be disabled in order to maintain correct functionality of the communication system. Please contact the panel vendor for details on how to disable the second telephone line.**

## GS3055-I CF Connections Description

---

### *GS3055-I CF Module*

**⏏ (1) Earth Ground** - This terminal must be connected to the Mains Earth, in order to comply with the Telecommunications Network Safety Standards (Overvoltage Protection Requirements).

**TIP (2) / RNG (3) External telephone line** - These terminals must be connected directly to the incoming telephone line.

**T1 (4) / R1 (5) Internal telephone line** - These terminals must be connected to the TIP and RING of the control panel.

**COM(6,14) Common** - This terminal is connected internally to Power Ground.

**PGM1 (7), PGM2 (8), PGM3 (9), PGM4 (10)** Programmable type open-collector outputs. These outputs can be activated by programmed events. Refer to "Outputs" section for details. The maximum current sink of each output must not exceed 50mA. PGM1, PGM2 and PGM3 are active low and PGM4 is active high.

**AUX+ (11) Auxiliary 12V Output** - Special applications output, power-limited, 200mA PTC Protected. This terminal is used in conjunction with the PGM outputs to activate a supervision relay. Recommended relay: DSC Model RM-2.

**NOTE: Current drawn from this terminal is directly drawn from the power supply.**

**Tamper (12-13)** - These terminals are connected in series to the Tamper microswitch [8]. They will be closed when the cabinet is properly closed, and will open when the front cover is removed.

**Z1-Z4 (15-16-17-18) Inputs** - These terminals are set up to trigger events. Refer to "Inputs Activation Mode" section for details.

**+12V (19), -12V (20) Device Power Supply** - These terminals must be connected to the output of the power supply [10]. When the connections are completed, connect the Red and Black wires [12] to a 12V, 7Ah battery [13].

### *Power Supply Module*

**AC** - Supervised input, connect the secondary of the transformer to these terminals. Connect the primary of the transformer to a dedicated electrical circuit.

**+12V/COM** - Special application output circuit, power limited, connect to GS3055-I CF power input circuit. Connect the +12V output to +12V input on the GS3055-I CF module and the COM output to the -12V input on the GS3055-I CF module.

**ACT (AC Trouble)** - This open collector output activates when an AC Trouble is detected: Rated 50mA.

**NOTE: AC Trouble output shall be connected to an input on the alarm control panel that provides immediate local annunciation and delayed remote transmission for 1 to 3 hours. If such input is not able to provide the delay for AC loss transmission, input 1 of the GS3055-I CF can be used. When Input 1 is triggered, the GS3055-I CF will immediately annunciate an AC trouble by flashing the RED status LED 9 times, and will delay the AC loss event transmission by 2 hours.**

**LBT (Battery Trouble)** - This open collector output activates when a Battery Trouble condition is detected: Rated 50mA.

**TEST (Charger Trouble)** - This open collector output activates when the charging circuit is in a trouble condition: Rated 50mA.

These outputs shall be connected to zone inputs of an alarm control panel in order to provide the required trouble supervision (visual and audible indication required at the control panel). The outputs are active low (switched to ground) and can be connected to a control panel directly or by using a listed supervision relay (suggested model: DSC, RM-2 Relay).

**+BAT/-BAT** - This connector is used to connect the standby battery, non-power limited. Use single lead battery wire assembly provided.

**NOTE: When disposing of batteries, follow the instructions and precautions printed on the batteries, and contact your municipal offices for information on the disposal of used batteries.**

## Status LEDs

---

The GS3055-I CF has 4 LEDs used for local indication of module functionality, status (trouble conditions) and receiving signal strength.

**▲ RED** — This LED is Normally OFF, but will blink in the event of trouble. This LED will switch ON within 3 minutes in the event of GSM Radio [5] trouble, or when the GSM Network is unavailable (NO SERVICE). If this LED blinks, the following list indicates the specific trouble based on the number of blinks, by priority. On power-up, the GS3055-I CF will check for trouble conditions to be restored in the order listed below. It will indicate the status of the highest priority, unrestored trouble condition with the corresponding number of flashes of the RED LED.

When the highest priority trouble condition has been cleared, the next highest priority trouble condition will be displayed.

**1 flash** - Power Trouble (*low input voltage*)

**2 flashes** - Radio/SIM Failure (*check SIM card connection*)

**3 flashes** - GSM Network Problem (*SIM card not active, poor signal strength, antenna not connected*)

**4 flashes** - Insufficient Signal Strength (*poor location*)

**5 flashes** - Connect 24 Configuration SMS Failure (*improper VRU programming*)

When the configuration is ready, remove power for 2-3 seconds to allow the unit to restart and recheck status.

**6 flashes** - Receiver Not Initializing (*improper VRU programming*)

**8 flashes** - Primary Receiver absent (*receiver not acknowledging*)

**9 flashes** - AC Trouble (Input 1) triggered.

**Off** - No Troubles



**YELLOW** — This LED will switch ON when the GSM Network is in use. This LED can also blink quickly once (GPRS TX) or twice (GPRS RX).

**NOTE: The top two LEDs will blink during the initialization activation stages.**



**GREEN (Top)** — When this LED is **ON**, the reception is optimal. This LED will switch ON only when the other GREEN LED is ON.



**GREEN (Bottom)** — If this LED is **OFF** and the RED LED is ON, the GSM Network service is unavailable (**NO SERVICE**). This LED will **Blink** when the GSM Network reception is bad. If this LED is **ON**, the **GS3055-I CF** will be able to communicate to the GSM network.



## Operating Modes

---

### Simulated Land Line (Dialer) Mode

The simulated land line mode provides the fire alarm control panel (with dialer interface) with a communication path for standalone type applications (GSM/GPRS network being the sole communication technology used) or for back-up type applications (where two communication technologies PSTN and GSM-GPRS are used).

In applications where the GS3055-I CF is also connected to the telephone line (back-up configuration), if the voltage on the land line terminals (**TIP/RNG**) drops below 4V for a period of 10 to 45 seconds (depending on the device connected to the **T1/R1** terminals), the GS3055-I CF will switch the connected alarm control panel to the GSM Network for approximately 30-40 seconds. At the end of this interval, it will check the land line and do one of the following:

- if the land line is restored, it will switch the connected alarm control panel back to the land line;
- if the land line is still down, it will continue to simulate the land line until it is restored. The GS3055-I CF will not switch during ongoing calls.

The communication of an event follows the sequence below:

- When an event is triggered, the alarm control panel dialer goes off-hook
- The GS3055-I CF will assert dial tone
- The Alarm Control Panel dials the number of the central station. Ensure the alarm control panel inserts a 1-second pause (minimum), or has dial tone search enabled before dialing the number
- The GS3055-I CF detects the DTMF dialing and stops the dial tone

**NOTE: The GS3055-I CF is unable to decode pulse dialing.**

- The GS3055-I CF will send the required Contact ID dual tone handshake to the alarm control panel
- After receiving the handshake, the alarm control panel transmits the event alarm message in Contact ID format
- The GS3055-I CF decodes and transforms the Contact ID digits into an IP packet and sends it to the Supervising Station Receiver over the GSM GPRS network
- The receiver acknowledges the received event and sends a command to the GS3055-I CF to generate the corresponding 1400Hz kiss-off signal for 800ms minimum
- After the GS3055-I CF generates the kiss-off, the alarm control panel sends the next event or goes on-hook if no more events need to be sent.

## Inputs Activation Mode

The GS3055-I CF also has 4 inputs that can be used to trigger specific event transmissions. The events associated with these inputs will be transmitted using Contact ID Communication Format. The default settings for these inputs (as they should be correlated at the supervising station) are:

INPUT 1- AC LOSS                      INPUT 3 - FIRE ALARM  
INPUT 2 - FIRE SUPERVISORY      INPUT 4 - TROUBLE

These inputs are normally open type and will activate when a short condition is detected between the terminal and the COM. Refer to the GS3055-I CF Wiring Diagram (Figure 2) at the back of this manual.

**NOTE: When the GS3055-I CF is configured in Land Line Mode, these inputs should be restricted to monitoring of trouble conditions.**

**NOTE: For UL listing, connections between alarm panel outputs and GS3055-I CF inputs shall be run in mechanical protective conduit within 20ft and in the same room. To reduce interference with the antenna, it is recommended that metal conduit is not connected to the knock-outs on the top of the cabinet.**

## Outputs

The GS3055-I CF has 4 open collector outputs, switched to ground, capable of a maximum of 50mA. Internal events on the GS3055-I CF can trigger the outputs to turn on an LED or activate an input on the alarm control panel. The default settings are as follows:

**OUTPUT 1 - Land Line Trouble:** Output is normally high and will switch to ground when the telephone line is down.

**NOTE: This output is not required when the GS3055-I CF is used as a standalone device.**

**OUTPUT 2 - GSM Module or Network Trouble:** Output is normally high and will switch to ground when the GS3055-I CF cannot connect or communicate to the GSM network.

**OUTPUT 3 - Activation:** Output is normally high and will switch to ground during activation.

**OUTPUT 4 - General Module Trouble:** Output is normally low and will switch to high when any of the previous troubles occur and/or a Failure to Communicate (FTC) trouble is detected.

**NOTE: Once an output has been activated automatically, it will not restore its state until all the causes of activation are cleared.**

## Contact ID Events Description

### Event Codes

Input 1 Activation: .....	E301 AC LOSS ZONE 991
Input 1 Restoral: .....	R301 AC LOSS ZONE 991
Input 2 Activation: .....	E200 Fire Supervisory ZONE 992
Input 2 Restoral: .....	R200 Fire Supervisory ZONE 992
Input 3 Activation: .....	E110 FIRE ZONE 993
Input 3 Restoral: .....	R110 FIRE ZONE 993
Input 4 Activation: .....	E300 System Trouble ZONE 994
Input 4 Restoral: .....	R300 System Trouble ZONE 994
PSTN Line Down: .....	E351 TELCO 1 FAULT 000
PSTN Line Restoral: .....	R351 TELCO 1 FAULT 000
Periodic Report: .....	E603 Periodic RF Xmission 000
Periodic report with off-normal condition ..	E608 Periodic Test Xmission with System Trouble Present 000
GSM UNIT ACTIVATION: .....	R552 Radio Xmitter Disabled 000
GSM INTERNAL BUFFER FULL: .....	E624 EVENT LOG OVERFLOW 000
FTC RESTORAL: .....	R354 FAILURE TO COMMUNICATE 000

**NOTE: The GS3055-I CF does not support local or remote programming. Upon activation through Connect 24 the product will operate as described in the previous sections of this manual.**

# APPENDIX - Wiring Diagrams

**Fig. 2 - GS3055-I CF Module Wiring Diagram**

**WARNING!**  
HIGH VOLTAGE. DISCONNECT AC  
POWER & TELEPHONE LINES  
PRIOR TO SERVICING

**This Connection is necessary**

**GROUND CONNECTION**  
Tighten nut to break point and make good connection to the cabinet.  
Rep-Nut  
Cabinet  
Bolt  
Earth-ground

**Telephone Line Connection**  
(Use No. 26 AWG wires for the connection to PSTN)  
Phone line connection is required only for back-up configurations. In stand-alone applications, no other communication technology is required for Fire Alarm Monitoring. Refer to Fig. 4 for wiring details.

**Suggested compatible DACT models for use with GS3055-I CF are DSC models:**  
PC4020CF with PC4701 Interface or  
PC5020CF with PC5700 Interface

**Alarm Control Panel with Dialler Interface (Supports Contact ID format)**

**RM-2 Relay**  
1K5  
optional use of PGM output (See Programming)  
Connect relay contacts to a zone input on the alarm control panel for GS3055-I CF troubles supervision (24h type zone)

**Connect to Power Supply Terminals +12V/COM**

**Inputs to be connected to dry contact outputs from alarm control panel 12V / 1mA**

**These inputs are typically used to interface with fire alarm panels that do not have a dialer interface and use the fire alarm, fire supervisory or fire trouble output relay contacts to send the events to the communicator.**


**Tamper Output**

**GS3055-I CF**

**TERMINALS:** 1 TIP, 2 RING, 3 TI, 4 RI, 5 COM, 6 PGM1, 7 PGM2, 8 PGM3, 9 PGM4, 10 AUX+, 11 TAMPER, 12 COM, 13 Z1, 14 Z2, 15 Z3, 16 Z4, 17 +12V, 18 COM, 19 Z1, 20 Z2.

**NOTE:** If the control panel PGM output connected to the GS30XX input latches (remains closed) after an alarm has occurred, the GS30XX input will remain active. The latched PGM output must be reset or future alarms will not be reported via the zone input of the GS30XX and additional alarms may be triggered when the GS30XX is locally or remotely restarted. Please contact panel vendor for details on how to reset the control panel PGM.


**Fig. 2 - GS3055-I CF Module Wiring Diagram**



**WARNING:** Incorrect connections may result in PTC failure or improper operation. Inspect wiring and ensure connections are correct before applying power. All circuits are classified for UL installations as Power Limited/Class II Power Limited except for the battery leads which are not power limited. Do not route any wiring over circuit boards. Maintain at least 1" (25.4mm) separation. A minimum 1/4" (6.4mm) separation must be maintained at all points between Power Limited wiring and all other Non-Power Limited wiring. Route wires as indicated in the diagram.


NOTE: If the control panel PGM output connected to the GS30XX input latches (remains closed) after an alarm has occurred, the GS30XX input will remain active. The latched PGM output must be reset or future alarms will not be reported via the zone input of the GS30XX and additional alarms may be triggered when the GS30XX is locally or remotely restarted. Please contact panel vendor for details on how to reset the control panel PGM.

**Fig. 2a - GS3055-ICF Module Wiring Diagram - Standalone Configuration**




NOTE: If the control panel PGM output connected to the GS30XX input latches (remains closed) after an alarm has occurred, the GS30XX input will remain active. The latched PGM output must be reset or future alarms will not be reported via the zone input of the GS30XX and additional alarms may be triggered when the GS30XX is locally or remotely restarted. Please contact panel vendor for details on how to reset the control panel PGM.


**Fig. 3 - Power Supply Wiring Diagram**



**Fig. 4 - Telephone Connection (Not required when GS3055-I CF is used as a standalone device)**



**Fig. 5 - Optional Power Supply And Supervision Wiring Diagram**



- NOTES:**
1. Program the Control Panel's input Zone/Point as 24h "Supervisory" type with the keypad only annunciation when activated.
  2. A supervision relay, DSC model RM-2 can be used, as indicated in Fig. 4 in order to provide supervision of the control panel (for total power loss) when the GS3055-I CF is powered by a Separate Power Supply. When the GS3055-I CF is powered by the control panel the relay is not required since a loss of voltage at the power input terminals on the GS3055-I CF will generate a trouble signal transmission to the monitoring station.
  3. Output 4 on the GS3055-I CF must be set as "Active High".

## FCC COMPLIANCE STATEMENT

**CAUTION:** Changes or modifications not expressly approved by Digital Security Controls could void your authority to use this equipment. This equipment generates and uses radio frequency energy and if not installed and used properly, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for Class B device in accordance with the specifications in Subpart "B" of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in any residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to television or radio reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Re-orient the receiving antenna
- Relocate the alarm control with respect to the receiver
- Move the alarm control away from the receiver
- Connect the alarm control into a different outlet so that alarm control and receiver are on different circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the FCC helpful: "How to Identify and Resolve Radio/Television Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402, Stock # 004-000-00345-4.

## IMPORTANT INFORMATION

This equipment complies with Part 68 of the FCC Rules. On the side of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this number must be provided to the Telephone Company.

GS3055-I Product Identifier US: F53AL00BGS3055

REN: 0.0B

USOC Jack: RJ-31X

## Telephone Connection Requirements

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

## Ringer Equivalence Number (REN)

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call.

In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local Telephone Company. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format. US: AA AEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

## Incidence of Harm

If this equipment GS3055-I CF causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the Telephone Company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

## Changes in Telephone Company Equipment or Facilities

The Telephone Company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the Telephone Company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

## Equipment Maintenance Facility


If trouble is experienced with this equipment for repair or warranty information, please contact the facility indicated below. If the equipment is causing harm to the telephone network, the Telephone Company may request that you disconnect the equipment until the problem is solved. This equipment is of a type that is not intended to be repaired by the end user.

DSC c/o APL Logistics, 757 Douglas Hill Rd., Lithia Springs, GA 30122

## Additional Information

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

Alarm dialling equipment must be able to seize the telephone line and place a call in an emergency situation. It must be able to do this even if other equipment (telephone, answering system, computer modem, etc.) already has the telephone line in use. To do so, alarm dialling equipment must be connected to a properly installed RJ-31X jack that is electrically in series with and ahead of all other equipment attached to the same telephone line. Proper installation is depicted in the figure below. If you have any questions concerning these instructions, you should consult your telephone company or a qualified installer about installing the RJ-31X jack and alarm dialling equipment for you.



## Industry Canada Compliance Statement

This Equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that that Industry Canada approved the equipment. The Ringer Equivalence Number (REN) for this terminal equipment is 0.0. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all devices does not exceed 5. Cet équipement est conforme aux spécifications techniques applicables aux équipements terminaux d'Industrie Canada. Ceci est confirmé par le numéro d'enregistrement. L'abréviation IC précédant le numéro d'enregistrement signifie que l'enregistrement a été effectué sur la base de la Déclaration de conformité indiquant que le produit est conforme aux spécifications techniques d'Industrie Canada. Ceci n'implique pas que le produit ait été approuvé par Industrie Canada.

Le nombre équivalent de sonneries (REN) de cet appareil terminal est 0.0. Le REN attribué à chaque équipement terminal fournit une indication sur le nombre maximum de terminaux pouvant être connectés sur une interface téléphonique. La terminaison sur une interface peut constituer n'importe quelle combinaison d'appareils, à la condition seulement que la somme des Nombres équivalents de sonneries de tous les appareils ne soit pas supérieure à 5.

This Class B digital apparatus meets all requirements of the Canadian interference-causing equipment regulations. Cet appareil numérique de la Classe B respecte toutes les exigences de règlement sur le matériel brouilleur du Canada.

The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met. This manual is applicable to the following GS3055-I CF Cellular Alarm Communicator Models:

GS3055-1 FCC ID: F5306GS30551 and IC: 160A-GS30551

GS3055-2 FCC ID: F5306GS30552 and IC: 160A-GS30552

**WARNING:** To satisfy FCC RF exposure requirements for mobile transmitting devices, a separation distance of 20cm or more must be maintained between the antenna of this device and persons during device operation.

**IMPORTANT - READ CAREFULLY: DSC Software purchased with or without Products and Components is copyrighted and is purchased under the following license terms:**

- This End-User License Agreement ("EULA") is a legal agreement between **You** (the company, individual or entity who acquired the Software and any related Hardware) and **Digital Security Controls, a division of Tyco Safety Products Canada Ltd.** ("DSC"), the manufacturer of the integrated security systems and the developer of the software and any related products or components ("HARDWARE") which You acquired.
- If the DSC software product ("SOFTWARE PRODUCT" or "SOFTWARE") is intended to be accompanied by HARDWARE, and is NOT accompanied by new HARDWARE, You may not use, copy or install the SOFTWARE PRODUCT. The SOFTWARE PRODUCT includes computer software, and may include associated media, printed materials, and "online" or electronic documentation.
- Any software provided along with the SOFTWARE PRODUCT that is associated with a separate end-user license agreement is licensed to You under the terms of that license agreement.
- By installing, copying, downloading, storing, accessing or otherwise using the SOFTWARE PRODUCT, You agree unconditionally to be bound by the terms of this EULA, even if this EULA is deemed to be a modification of any previous arrangement or contract. If You do not agree to the terms of this EULA, DSC is unwilling to license the SOFTWARE PRODUCT to You, and You have no right to use it.

#### SOFTWARE PRODUCT LICENSE

The SOFTWARE PRODUCT is protected by copyright laws and international copyright treaties, as well as other intellectual property laws and treaties. The SOFTWARE PRODUCT is licensed, not sold.

##### 1. GRANT OF LICENSE. This EULA grants You the following rights:

- (a) **Software Installation and Use** - For each license You acquire, You may have only one copy of the SOFTWARE PRODUCT installed.
- (b) **Storage/Network Use** - The SOFTWARE PRODUCT may not be installed, accessed, displayed, run, shared or used concurrently on or from different computers, including a workstation, terminal or other digital electronic device ("Device"). In other words, if You have several workstations, You will have to acquire a license for each workstation where the SOFTWARE will be used.
- (c) **Backup Copy** - You may make back-up copies of the SOFTWARE PRODUCT, but You may only have one copy per license installed at any given time. You may use the back-up copy solely for archival purposes. Except as expressly provided in this EULA, You may not otherwise make copies of the SOFTWARE PRODUCT, including the printed materials accompanying the SOFTWARE.

##### 2. DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS.

- (a) **Limitations on Reverse Engineering, Decompilation and Disassembly** - You may not reverse engineer, decompile, or disassemble the SOFTWARE PRODUCT, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation. You may not make any changes or modifications to the Software, without the written permission of an officer of DSC. You may not remove any proprietary notices, marks or labels from the Software Product. You shall institute reasonable measures to ensure compliance with the terms and conditions of this EULA.
- (b) **Separation of Components** - The SOFTWARE PRODUCT is licensed as a single product. Its component parts may not be separated for use on more than one HARDWARE unit.
- (c) **Single INTEGRATED PRODUCT** - If You acquired this SOFTWARE with HARDWARE, then the SOFTWARE PRODUCT is licensed with the HARDWARE as a single integrated product. In this case, the SOFTWARE PRODUCT may only be used with the HARDWARE as set forth in this EULA.
- (d) **Rental** - You may not rent, lease or lend the SOFTWARE PRODUCT. You may not make it available to others or post it on a server or web site.
- (e) **Software Product Transfer** - You may transfer all of Your rights under this EULA only as part of a permanent sale or transfer of the HARDWARE, provided You retain no copies, You transfer all of the SOFTWARE PRODUCT (including all component parts, the media and printed materials, any upgrades and this EULA), and provided the recipient agrees to the terms of this EULA. If the SOFTWARE PRODUCT is an upgrade, any transfer must also include all prior versions of the SOFTWARE PRODUCT.
- (f) **Termination** - Without prejudice to any other rights, DSC may terminate this EULA if You fail to comply with the terms and conditions of this EULA. In such event, You must destroy all copies of the SOFTWARE PRODUCT and all of its component parts.
- (g) **Trademarks** - This EULA does not grant You any rights in connection with any trademarks or service marks of DSC or its suppliers.

#### 3. COPYRIGHT.

All title and intellectual property rights in and to the SOFTWARE PRODUCT (including but not limited to any images, photographs, and text incorporated into the SOFTWARE PRODUCT), the accompanying printed materials, and any copies of the SOFTWARE PRODUCT, are owned by DSC or its suppliers. You may not copy the printed materials accompanying the SOFTWARE PRODUCT. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE PRODUCT are the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants You no rights to use such content. All rights not expressly granted under this EULA are reserved by DSC and its suppliers.

#### 4. EXPORT RESTRICTIONS.

You agree that You will not export or re-export the SOFTWARE PRODUCT to any country, person, or entity subject to Canadian export restrictions.

#### 5. CHOICE OF LAW: This Software License Agreement is governed by the laws of the Province of Ontario, Canada.

#### 6. ARBITRATION

All disputes arising in connection with this Agreement shall be determined by final and binding arbitration in accordance with the Arbitration Act, and the parties agree to be bound by the arbitrator's decision. The place of arbitration shall be Toronto, Canada, and the language of the arbitration shall be English.

#### 7. LIMITED WARRANTY

##### (a) NO WARRANTY

DSC PROVIDES THE SOFTWARE "AS IS" WITHOUT WARRANTY. DSC DOES NOT WARRANT THAT THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT OPERATION OF THE SOFTWARE WILL BE UNINTERRUPTED OR ERROR-FREE.

##### (b) CHANGES IN OPERATING ENVIRONMENT

DSC shall not be responsible for problems caused by changes in the operating characteristics of the HARDWARE, or for problems in the interaction of the SOFTWARE PRODUCT with non-DSC-SOFTWARE or HARDWARE PRODUCTS.

##### (c) LIMITATION OF LIABILITY; WARRANTY REFLECTS ALLOCATION OF RISK

IN ANY EVENT, IF ANY STATUTE IMPLIES WARRANTIES OR CONDITIONS NOT STATED IN THIS LICENSE AGREEMENT, DSC'S ENTIRE LIABILITY UNDER ANY PROVISION OF THIS LICENSE AGREEMENT SHALL BE LIMITED TO THE GREATER OF THE AMOUNT ACTUALLY PAID BY YOU TO LICENSE THE SOFTWARE PRODUCT AND FIVE CANADIAN DOLLARS (CAD\$5.00). BECAUSE SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

##### (d) DISCLAIMER OF WARRANTIES

THIS WARRANTY CONTAINS THE ENTIRE WARRANTY AND SHALL BE IN LIEU OF ANY AND ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF DSC. DSC MAKES NO OTHER WARRANTIES. DSC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON PURPORTING TO ACT ON ITS BEHALF TO MODIFY OR TO CHANGE THIS WARRANTY, NOR TO ASSUME FOR IT ANY OTHER WARRANTY OR LIABILITY CONCERNING THIS SOFTWARE PRODUCT.

##### (e) EXCLUSIVE REMEDY AND LIMITATION OF WARRANTY

UNDER NO CIRCUMSTANCES SHALL DSC BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES BASED UPON BREACH OF WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY. SUCH DAMAGES INCLUDE, BUT ARE NOT LIMITED TO, LOSS OF PROFITS, LOSS OF THE SOFTWARE PRODUCT OR ANY ASSOCIATED EQUIPMENT, COST OF CAPITAL, COST OF SUBSTITUTE OR REPLACEMENT EQUIPMENT, FACILITIES OR SERVICES, DOWN TIME, PURCHASERS TIME, THE CLAIMS OF THIRD PARTIES, INCLUDING CUSTOMERS, AND INJURY TO PROPERTY.

**WARNING: DSC recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this SOFTWARE PRODUCT to fail to perform as expected.**

© 2011 Tyco International Ltd. and its Respective Companies. All Rights Reserved.  
The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco International Ltd. will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco International Ltd. are the property of their respective owners, and are used with permission or allowed under applicable laws.  
Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.



Tech Support: 1-800-387-3630 (Canada & U.S.) or 905-760-3036 • [www.dsc.com](http://www.dsc.com)  
Printed in Canada



29007393R007