#### FCC COMPLIANCE STATEMENT

**CAUTION:** Changes or modifications not expressly approved by Digital Security Controls Ltd. could void your authority to use this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Re-orient the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/television technician for help.

The user may find the following booklet prepared by the FCC useful: "How to Identify and Resolve Radio/Television Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington D.C. 20402, Stock # 004-000-00345-4.

## Warranty

Digital Security Controls Ltd. warrants that for a period of 12 months from the date of purchase, the product shall be free of defects in materials and workmanship under normal use and that in fulfillment of any breach of such warranty, Digital Security Controls Ltd. shall, at its option, repair or replace the defective equipment upon return of the equipment to its repair depot. This warranty applies only to defects in parts and workmanship and not to damage incurred in shipping or handling, or damage due to causes beyond the control of Digital Security Controls Ltd. such as lightning, excessive voltage, mechanical shock, water damage, or damage arising out of abuse, alteration or improper application of the equipment.

The foregoing warranty shall apply only to the original buyer, and is and shall be in lieu of any and all other warranties, whether expressed or implied and of all other obligations or liabilities on the part of Digital Security Controls Ltd. Digital Security Controls Ltd. Digital Security Controls Ltd. neither assumes responsibility, nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product. In no event shall Digital Security Controls Ltd. be liable for any direct, indirect or consequential damages, loss of anticipated profits, loss of time or any other losses incurred by the buyer in connection with the purchase, installation or operation or failure of this product.

**WARNING:** Digital Security Controls Ltd. recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected

**IMPORTANT INFORMATION:** Changes or modifications not expressly approved by Digital Security Controls Ltd. could void the user's authority to operate this equipment.



© 2003 Digital Security Controls Ltd. Toronto, Canada

Tech Support: 1-800-387-3630 • www.dsc.com • Printed in Canada





# HS-FDR, HS-PDR, HS-LDR Series - Cabinet Doors

### Installation Instructions

### Introduction

The HS-FDR, HS-PDR and HS-LDR series of cabinet doors are intended for use with the HS-CAB series of Cabinets including HS-CAB1000, HS-CAB3000 and HS-CAB4000.

**HS-FDR Series** - 16 gauge steel plate doors that secure to the cabinet with machine screws.

**HS-PDR Series** - bronze-smoked plastic versions of the HS-FDR series. **No** provision has been made on the HS-PDR series for the addition of a lock.

**HS-LDR Series** - steel plate doors that secure to the cabinet by inserting the door tabs into the slots provided at the bottom of the cabinet and locking in place.

## **Contents of Package:**

- Oty (1) Concourse Label for insertion into Label panel provided.
- Qty (1) Lock (HS-LDR series only)
- Qty (4) Mounting Screws (HS-FDR1000 and HS-PDR1000 only)
- Qty (6) Mounting Screws (HS-FDR3000, 4000 and HS-PDR3000, 4000 only)

	HS-CAB1000	HS-CAB3000	HS-CAB4000
		-	
	HS-FDR1000	HS-FDR3000	HS-FDR4000
HS-FDR Series	Height 16.25in (414mm)	Height 30.5in (775mm)	Height 44 in (1118mm)
Fastened Metal Door	Width 16.25in (414mm)	Width 16.25in (414mm	Width 16.25in (414mm)

	HS-PDR1000	HS-PDR3000	HS-PDR4000
HS-PDR Series	Height 16.25in (414mm)	Height 30.5in (775mm)	Height 44 in (1118mm)
Plastic Door	Width 16.25in (414mm)	Width 16.25in (414mm	Width 16.25in (414mm)


	HS-LDR1000	HS-LDR3000	HS-LDR4000
HS-LDR Series	Height 15.3in (389m)	Height 29.6in (752mm)	Height 43.9 in (1115mm)
Locking Door	Width 15.3 (389mm)	Width 15.3 (389mm)	Width 15.3 (389mm)

## Installation:

## HS-LDR Series Locking Doors Installation

- 1. Remove the knock-outs (1) for the tabs located at the bottom of the cabinet (preferably before mounting cabinet).
- 2. Install the lockset into the opening (2) provided at the top of the door.
- 3. Affix the Concourse label to the front of the door in the area provided.
- 4. Slide the door tabs (3) at the bottom of the door into the slots in the bottom of the cabinet.
- 5. Push the top of the door towards the cabinet until fully closed.
- 6. Insert the key into the lock and turn clockwise to lock the cabinet.

Figure 1, HS-LDR Installation




### **HS-FDR, HS-PDR Series**

### **Fastened Metal and Plastic doors Installation**

- 1. Affix the Concourse label to the front of the door in the area (1) provided.
- 2. Install two 1¼" panhead philips machine screws (supplied) in the top two holes (2) of the cabinet. Allow ¼" (min.) clearance for doors.
- 3. Position the two keyholes of the door (3) over the screws and hang the door from the two screws
- 4. Install remaining screws. Securely fasten all screws (4).

## Figure 2, HS-FDR, PDR Installation



### NOTE:

The PDR Series plastic doors do not have drilled keyways to facilitate mounting on cabinets. The door must be held in place when installing the first 2 screws.

## CAUTION:

Over tightening of screws on PDR Series plastic doors may result in damage to the door.

### WARNING:

The PDR Series plastic doors are not approved for UL/ULC installations.